SECOND SUPPLEMENT

# RECEIVING TUBE SUBSTITUTION GUIDEBOOK

BY
H. A. MIDDLETON



JOHN F. RIDER PUBLISHER, INC. 480 CANAL STREET NEW YORK 13, N. Y. Copyright 1954 by JOHN F. RIDER

All rights reserved. This book or parts thereof may not be reproduced in any form or in any language without permission of the publisher.

Printed in the United States of America

#### **FOREWORD**

This Second Supplement to the Receiving Tube Substitution Guidebook, in addition to the original volume and the First Supplement to it, is an accumulation of over twelve years of experience in substituting tubes in radios, television receivers and other electronic equipment. It is a never-ending process which we shall continue in an effort to keep your information as current as possible.

Most of these additional substitutions are for use in television receivers and therefore, because of their critical application in some cases, special consideration should be given your selection when you have a choice of substitutes. A stage-by-stage discussion of the most popular circuits used in television receivers is included in the First Supplement. If there is any question as to whether or not the stage being substituted is a critical one and which characteristics of the substitute should be given special consideration, take a moment to read the article covering the stage in question.

The information herein, in the large part, calls for substitutions only. It is not the object of these instructions to tell you how to improve radios, television receivers and other electronic equipment but rather to help you use the tubes you have, in order to replace those that are not available. Exceptions to the above statement are tubes especially designed as replacements of types where

improvement is needed generally or for specific use such as 5881 for 6L6, 5AW4 for 5U4G, 6CU6 for 6BQ6GT, and the same type numbers in ruggedized tubes designated by an additional ending letter, as 6SN7WGT. Types such as these are designed to improve the life of the tube, the efficiency of the circuit in which they are applied, or both. Characteristics are generally identical to the type they replace. Elements are heavier duty or especially treated in order to withstand greater overloads and construction is more rugged.

Also included in this supplement is a cumulative index indicating the volume and page where the tube you wish to substitute is located.

We have endeavored to list all the practical substitutions. Some, no doubt, have been omitted. When considering substitution, others not listed will likely come to mind. When this happens, write the tube number down immediately in the form used here and attach it in its proper place.

This supplement includes picture tube substitutions. It is recommended that before substitution of picture tube is attempted, a few moments be taken to read over the short article which precedes the picture tube section.

Phoenix, Arizona January, 1954

H. A. Middleton

# TABLE OF CONTENTS

SECTION 1 — RECEIVING TUBE SUBSTITUTIONS	Page
	_
SECTION 2 — PICTURE TUBE SUBSTITUTIONS	13
Substituting Picture Tubes in TV Receivers	13
Picture Tube Substitutions	15
CUMULATIVE INDEX	27
Receiving Tubes	27
Picture Tubes	39

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
1B3	1AX2 1X2A	E E	Change socket to noval and rewire as follows:  No. 2 on octal to No. 2 noval  to 8
			O O O O O O O O O O O O O O O O O O O
			Pins 3 and 7 may be used as tie points for filament and high voltage filter resistors.
1D5GP	1N5GT	G	Parallel circuits — add 10 ohm 1/2 watt resistor in series with filament circuit.
			Series circuits — in addition to above resistors, shunt a 200 ohm $1/2$ watt resistor across the combination.
	1P5	G	Same as above.
1X2 1X2A	1AX2	E	It may be necessary to increase the filament current by removing the filament resistor or adding a turn to the filament loop.
5AW4	5U4 5X4 5V4	G G	No changes.
5AZ4	5AW4		
5R4GY	5AW4		
5T4	5AW4		
5U4	5AW4		
5V4	5AW4		
5W4	5AW4	,	
5X4	5AW4		
5Y3	5AW4		
5Y4	5AW4		
5 <b>Z</b> 3	5AW4		
5 <b>Z</b> 4	5AW4		
6AB4	6AQ6	P	Rewire as follows:  Remove wires anchored on No. 5 and tape up.
			Disconnect No. 2 if grounded. No. 7 to No. 2
			1 to 7 6 to 1
			Connect Nos. 5 and 6 to chassis.
	6AV6	P	Same as above. Parallel circuits only.
	6BF6 6BK6	P P	baille as above. I a arrest cultures only.
	6BT6 6BU6	P P	
6 <b>AF</b> 4	6AN4	G	No changes.
6AG5	6CF6	G	

6AH4-6AK5 SUPPLEMENT—RECEIVING TUBE SUBSTITUTION GUIDE				
TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY	
6AH4	6BL7 6BX7	E	Parallel circuits only. Rewire as follows.  No. 8 to No. 3 2 to 8	
			(S)	) (9) (9) (9) (9) (9) (9) (9) (9) (9) (9
			Connect together Nos. 3 & 6, 2 & 5, 1 & 4.	
	6F6 6K6 6L6 6U6 6V6 6W6	G G E E E E E	Parallel circuits only. Rewire as follows:  No. 5  to No. 3 & 4  to 5  Parallel circuits only. Rewire as follows:	© 3 © 0 0 0 Sue.
			No. 8 to No. 3 to 8	6 9 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
			Connect together Nos. 3 & 6, 2 & 5, 1 & 4.	
	12AU7 12BH7	E	Parallel circuits only. Change socket to noval and rewire as follows:  No. 1 to No. 2  5 to 1  8 to 3  2 to 9  7 to 4  Connect together Nos. 1 & 6, 2 & 7, 3 & 8,	9 9 30 4 & 5.
6АН6	6CH6	G	Parallel circuits only. Change socket to noval and rewire as follows:  No. 1 to No. 2  2 to 9  3 to 4  to 5  5 to 7  6 to 8  7 to 3  Nos. 1 and 6 are internal connections in the tube. Do not use these for tie points.	SOO O O O O O O O O O O O O O O O O O O
6AJ4	6AM4	G	No changes.	
6AJ5	6CF6	P	Parallel circuits only. No changes.	
6AJ8	12AH8	G	This will operate if pins 7 & 9 are connected together.  Rewire as follows:  Remove wires from No. 9 and put them on N  Remove wires from No. 4 (or 5) and put them  No. 9. Connect No. 4 to No. 5.	o. 7. n on
			GO CORNOL	) (0) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1

6AK5

6CF6

G

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6AK6	6AM5	G	Parallel circuits only. Rewire as follows: No. 7 to No. 2
			6 to 7
			O SUB.
6AK8	<b>6T8</b>	E	No changes.
6AM4	6AJ4	E	No changes.
	6AN4	G	Change socket to 7 pin and rewire as follows:
·	•		All connections to Nos. 1, 3, & 4 must go to No. 2. All connections to Nos. 6 & 9 must go to No. 6. Then as follows:
			No. 2 to No. 5 to 1 or/& 7
			7 to 3 (1) one. 8 to 4
	6Q4	G	Parallel circuits only. Rewire as follows:  No. 3 to No. 1  (Let any other connections to No. 1 stay there).
			2 to 3 4 to 2
			7 to 4
			9 to 7 to 9
			8 to 5 <b>6</b> to 8
6AM5	6AK6	E	Heater current different, make necessary changes in series circuit. Rewire as follows:
			Remove wires from No. 6 and tape up. No. 6 to No. 7
			Connect Nos. 7 and 2 together.
			ORIG. Sup.
CANA	0454	•	No shakara
6AN4	6AF4 6T4	G G	No changes. No changes.
	6AM4	G	Change socket to noval and rewire as follows:  Connections to No. 2 may be distributed between
			Nos. 1, 3, & 4. Connections to No. 6 may be split up between
		* * * 1	Nos. 6 and 9. Then as follows:  No. 4 to No. 8
			3 to 7 to 5 to 5 to 2
6AQ5	6BM5	E	No changes.
6AS5	6BM5	G	Parallel circuits only. Same as 6AS5 to 6AQ5.
6AV6	<b>6</b> B <b>T6</b>	G	No changes.
6BA6	6CG6	G	
6BC5	6CF6	G	
6BJ6	6BA6 12BA6	E	Parallel circuits only. No changes. Series circuits only. No changes.

6BK5-6B	<b>15</b>	SUPPLEA	MENT—RECEIVING TUBE SUBSTITUTION GUIDE
TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6BK5	6BW6	G	Parallel circuits only. Rewire as follows:  Remove and tape up any wires connected to No. 2 and No. 9.  No. 1 to No. 7  3 & 7 to 1 & 2  6 to 9  Connect Nos. 3 and 9 together.
<b>8</b>	5686	<b>P</b>	Parallel circuits only. Rewire as follows:  Remove and tape up any wires on No. 2 and No. 9  No. 3 & 7 to No. 2  1 to 7  6 to 3  8 to 6  Do not use any other pins for tie points.
6BK7	6BQ7 6BZ7 5670	G G G	No changes. No changes. Parallel circuits only. Rewire as follows: Reverse 1 & 4  2 & 3  5 & 9
6BL7	6BX7	E	No changes.
6BM5	6AQ5	E	No changes.
6BQ6	6CU6	E	No changes.
6BQ7	6BK7 6BZ7 5670	G E G	No changes. No changes. Same as 6BK7 to 5670
6BT6	6AV6	E	No changes.
6BW6	6BK5	G	Parallel circuits only. Rewire as follows:  Tape up any wires connected to No. 6.  No. 1 & 2 to No. 3 or/& 7  3 to 6 7 to 1 9 to 6 9 sup
6BX6 ·	6BY7	E	No changes.
6BX7	6BL7	E	No changes.
6BY5	5V4	<b>G</b>	This may be used if the two cathodes of the 6BY5 are connected together, and are also connected to the heater.  Connect No. 1 and No. 2 together.  No. 8 to No. 1 & 2  5 to 6
			(S)
			Connect a 10 watt $1/2$ ohm resistor in series with one side of heater.
	6AX6	E	Parallel circuits only. Rewire as follows:  No. 4 to No. 3  to 4  The downer actual array both sections are paralleled.
	6AX4	G	In damper service where both sections are paralleled.

6BY5-6CG6

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6BY5	6U4 6W4	P G	Rewire as follows:  No. 1 & 8
6BY7	6BH5	G	Rewire socket as follows:  Remove any wires from pin No. 6 and tape up. In series circuit shunt 68 ohm 1 watt resistor across 4 & 5.  No. 1 to No. 3  7 to 6  8 to 1  9 to 3  Note — pins 7 and 8 are internal connections on the 6BH5 and must not be used for tie points. No. 9 may be used for a tie point.
6BZ <b>7</b>	6BX6 6BK7 6BQ7 5670	E G E G	No changes.  No changes.  No changes.  Same as 6BK7 to 5670
6C4	6AQ6 6AV6 6BF6 6BK6	P P P	Rewire as follows:  Remove and tape up wires connected to No. 2.  No. 7 to No. 2  1 & 5 to 7  6 to 1  Connect Nos. 5 and 6 to chassis.  Same as above. Parallel circuits only.
6C5	6BT6 6BU6 12AT7	P P	Same as 6C5 to 12AU7. In addition, connect together Nos. 1 and 6, 2 and 7, 3 and 8.
	12AU7	E	Change socket to noval and rewire as follows:  Remove and tape up any wires connected to  Nos. 1, 4 and 6.  No. 2 to No. 4 & 5  3 to 1  5 to 2  7 to 9  8 to 3
	12AV7 12AX7 12AZ7 12BH7	G P G G	Same as 6C5 to 12AU7. Parallel circuits only. Same as 6C5 to 12AU7. Same as 6C5 to 12AU7. Parallel circuits only. Same as 6C5 to 12AU7. Parallel circuits only.
6CB6	6CF6	E	No changes.
6CG6	6AG5 6AH6 6AJ5 6AK5	G G G	Remove and tape up wires on No. 2. Parallel circuits only. No changes. Same as 6CG6 to 6AG5. Same as 6CG6 to 6AG5.

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6CG6	6AM6	G	Rewire as follows:
ocao	0.40	ď	Remove wires from No.2.
			No. 7 to No. 2
			6 to 7
			(0 0)
			( ) ( ) ( ) ( ) ( ) ( ) ( ) ( ) ( ) ( )
			ORIG. SUB.
			Wires removed from No. 2 connect to No. 6.
	6AU6	G	No changes.
	6BA6	G	No changes.
	6BC5	G	Same as 6CG6 to 6AG5.
	6BD6	${f E}$	No changes.
	6BH6	G	Parallel circuits only. Reverse Nos. 2 and 7.
	6BJ6	G	Parallel circuits only. Reverse Nos. 2 and 7.
	6CF6	G	
CODE	CACE		No obongo
6CF6	6AG5	G	No changes.
	6AJ5	P	Parallel circuits only. No changes.
	6AK5	G	No changes.
	6AK6	G	Parallel circuits only. Change connections as follows:
	0.4770	•	Reverse connections between terminals 2 and 7.
	6AU6	G	Change connections as follows:
	073.4.0	•	Reverse connections between terminals 2 and 7.
	6BA6	G	Same as 6CF6 to 6AU6.
	6BC5	G	No changes.
	6BD6	G	Same as 6CF6 to 6AU6.
	6CB6	E	Direct substitute.
	6CG6	G	Same as 6CF6 to 6AU6.
	5590	G	No changes.
	5591	G	
	5654	<b>G</b>	
	9001	$\mathbf{P}$	
	9003	P	
6СН6	6AH6	P	Parallel circuits only. Change socket to 7 pin and rewire as follows:
00110	01110	•	No. 2 to No. 1
			60a 3 to 7
			5 to 4 6 8
			ORIG. 7 to 5 sum
			8 to 6
			9 to 2
			3 60 2
6CK6	6CL6	G	Rewire as follows:
00110	0020	ď	Reverse Nos. 1 and 3
			Reverse Nos. 6 and 7
			Remove and tape up wires on Nos. 8 and 9.
			a Tremove and tape up when on 1405. United 5.
			ORIG SUB
6CL6	6AQ5	G	Change socket to 7 pin and rewire as follows:
	0.1.40	_	No. 2 & 9 to No. 1 & 7
			600 1 & 7 to 2
			6 6 5 to 4 6 6
			onic 6 to 5
	1		3 & 8 to 6
			In series circuits, shunt 20 ohm 2 watt resistor across
			Nos. 3 and 4.
	6BK5	G	Parallel circuits only. Rewire as follows:
	ODKO	G	Reverse No. 1 and No. 6.
			No. 7 to No. 6
			10 No. 7 to No. 8
			9 to 7
			ORIG. 9 LO 7 SUB.
			2 W 3

		301166	MENT—RECEIVING TOBE JOBSTITOTION GOIDE	BUL
TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY	
6CL6	6BV7	G	Parallel circuits only. Rewire as follows:	
			No. 8 to No. 3  2 & 9 to 8  6 to 2	
			If Nos. 1 and 7 are tied together, leave as is; No. 7 is grounded and No. 1 goes through a b network, remove the ground from No. 7 and moleads from No. 1 to No. 7.	ias
	6BW6	P	Parallel circuits only. Rewire as follows:  No. 9  to No. 2  to 8  to 8  foliate to 3  foliate to 3  foliate to 9  foliate to 7	
	6BY7	G	Parallel circuits only. Rewire as follows:  No. 9 to No. 2  7 to 9  6 to 7  3 to 8  Ground No. 6	<b>)</b>
	6CK6	G	Rewire as follows:  Reverse No. 1 and No. 3  Reverse No. 6 and No. 7  No. 8 to No. 1  Ground No. 8	
	6M5	G	Rewire as follows:  No. 9 to No. 2  Remove wires from No. 3.  No. 1 & 7 to No. 3  to 1  to 7	
			Connect wires removed from No. 3 to No. 1	
6CS6	6BE6	G	No changes.	
6CU6	6BQ6GT	E	No changes.	
<b>6J</b> 5	12AT7	<b>G</b>	This substitution utilizes both halves of the dual triode in para as the replacement tube. Same as 6J5 to 12AU7. In addition, connect Nos. 1 to 6, 2 to 7, and 3 to 8.	allel
	12AU7	E	This substitution utilizes one half of the dual triode as the replement tube. Change socket to noval and rewire as follows:  Remove and tape up any wires connected	lace-
			to Nos. 1, 4 and 6.  No. 2 to No. 4 & 5  3 to 1  5 to 2	
			7 to 9 8 to 3	
	12AV7	G	Same as 6J5 to 12AU7. Parallel circuits only.	
	12AX7	P	Same as 6J5 to 12AT7.	
	12AZ7	G	Same as 6J5 to 12AU7. Parallel circuits only.	
	12BH7	G	Same as 6J5 to 12AU7. Parallel circuits only.	
6M5	6CL6	G	Reverse 6CL6 to 6M5 procedure.	

6Q4-6U8	}	SUPPLEMEN	T—RECEIVING	G TUBE SUBSTITE	UTION GU	JIDE	
TUBE	SUB.	PERF.	CIRCUIT	CHANGES NECE	SSARY		
6Q4	6AM4	G F	Parallel circuits	only. Rewire as Remove and tape No. 8 5 9 7 4 2 3 Do not use No. 3	up any co to No. 6 to 8 to 5 to 9 to 7 to 4 to 2		No. 6.
	6R4	G F	Parallel circuits	only. Rewire as All connections ( moved to No. 1 No. 9	follows: to Nos. 1, to No. 8		nust be
6R4	6Q4	G P		only. Rewire as Remove and tape Nos. 2, 7 and 9 No. 8	follows: up any cor to No. 9	nnections to	See Superior
6S8GT	6R8	G P	Parallel circuits	only. Change so No. 1 on octal 2 3 4 5 6 7 8 top cap	to No. 1 to No. 1 to 7 to 2 to 6 to 3 to 9 to 4 to 5	al and rewi	re as follows:
	6V8	E P	Parallel circuits	only. Change so No. 1 on octal 2 3 4 5 6 7 8 top cap	to No. 2 to 3 to 7 to 8 to 8 to 1 to 4 to 5 to 6	val and rew on noval	re as follows:
6SN7	6BL7 6BX7	E P	arallel circuits	only. No change	s.		
<b>6T4</b>	6AN4	G N	lo changes.				
<b>6T8</b>	6AK8	G N	lo changes.				
6U3	6V3	E P	Parallel circuits	only. Rewire as No. 3	follows: to top ca	ıp	
6U8	6X8	G F	Rewire as follow	ws ( only if Nos. 7 No. 1 2 3 6 7 & 8 9 Connect Nos. 1 a	to No. 3 to 7 to 8 to 9 to 6		er):

	· OVID	DDD 25	GIRGIAN GWANGRO NEGROARY
TUBE 6V3	SUB. 6U3	PERF. G	CIRCUIT CHANGES NECESSARY  Parallel circuits only. Rewire as follows:
643	003	ď	(Be careful not to exceed the tube rating)
			to No. 3
			ORIG.
6V5GT	6V6GT	E	Rewire as follows:
04301	OVOGI	E	Remove and tape up any wires connected to No. 2
			Connect Nos. 8 and 2 together.
			ORIG.
6W6	6G6	P	Parallel circuits only. No changes.
	6L6 5881		
		<b>a</b> .	Damina on fallows
6X8	6U8	G	Rewire as follows:  Connect Nos. 7 and 8 together.
			Nos. 1 & 6 to No. 8  2 to 9
			(2) 3 to 1
			7 to 2 6 9 sue.
			9 to 6
12A4	12AU7	G	Rewire as follows:
			Remove and tape up any wires connected to Nos. 6 and 8.
			(2000) No. 1 to No. 3 & 8
			3 to 9 to 1 & 6
			Connect Nos. 2 and 7 together.
	12B4	G	No changes.
	12BH7	G	Same as 12A4 to 12AU7.
12AH8	6AJ8	G	This will work if the 12AH8 was operating on 6 volts.
			Rewire as follows:  Remove jumper between Nos. 4 and 5. No.
			9 to Nos. 4 or 5 (whichever has no connection)
			Connect Nos. 7 and 9 together.
			ORIG.
12AK7	12AX7	$\mathbf{E}$	No changes.
12AT6	6AQ6	E	Series circuits only. No changes.
12B4	12A4	G	No changes. For other substitutes see 12A4.
12BY7	6BY7	E	This can be used only where the 12BY7 is operating on 6.3 volts.
			Parallel circuits only. Rewire as follows:  Remove wires from No. 4 to 5 then No. 6 to No. 4
			Ground No. 6 (internal shield)
			If No. 3 is grounded, remove the connections from this point. If No. 9 is free, ground it or connect
			to No. 1.
			ORIG. SUB.
12BZ7	12AX7	E	Parallel circuits only. No changes.
1288	19T8	E	Same as 6S8 to 6T8.
	19V8	E	Same as 6S8 to 6V8.

125K7-19Y	<b>'3</b>	SUPPLEMEN	IT—RECEIVING	TUBE SUBSTIT	TUTION (	GUIDE	
TUBE	SUB.	PERF.	CIRCUIT	CHANGES NECI	ESSARY		
12SK7	12887	E		t in series circu erminals, Nos. 2		150 ohm 1 wa	tt resistor
12SQ7	26BK6	G	Series circuits resistor across	only. Same as 1 Nos. 3 and 4.	28Q7 to 1	12BK6. Add	300 ohm 2 watt
12887	12SK7	E	See page 12, Se	circuit changes			heater current.
12V6	12A5	G	Change socket	to small 7 pin ar No. 2 on octal		as follows:  o. 1 on 7 pin	
			00	3	to	2	602
· .			(@(	<b>4</b> 5	to to	3 4	(8° 8)
			ORIG.	7	to	<b>7</b> .	\$ <b>U</b>
				8	to	5	
12X4	6X4	E					s with the heater.
	6X5	E	Same as 6X4 to with the heater.	6X5, except to	add a 20	ohm 5 watt re	sistor in series
14X7	<b>19T8</b>	G.	Series circuits	only. Change s	ocket to n	noval and rew	ire as follows:
			<b>(00)</b>	No. 1 on loctal	l to No to	o. 4 on noval	
			$(^{\circ}\bigcirc^{\circ}\bigcirc$	3	to	8	<b>6</b>
				4	to	7	
			OHIG.	ა 6	to	1 or/& 6 2	SUB.
				7	to	.3	
				. 8	to	5	
	19V8	E	Series circuits	only. Change so No. 1 on loctal	l to No	o. 4 on noval	ire as follows:
				2 3	to to	1 6	600
				4	to	3	
			ORIG.	5 6	to to	9 or /& 2 7	SUB.
				7	to	8	
				- 8	to	5	
19AQ5	16A5	G	Change socket	to noval and rev	vire as fo	llows:	
101140	20220	<del>-</del>		No. 1 & 7	to N	o. 2	
			600	2 3	to to	3 4	
			(B) (B)	4	to	5	
			<b>29</b>	5 6	to to	7 9	
			•	Nos. 6 and 8 a			8
				Do not use for			
							٠
	35B5	G	Series circuits provide the ext	only. Some circ ra 15 filament ve	cuit chang olts. No	ges may be ne other changes	ecessary to
19J6	<b>6</b> J6	E	Rewire as follo		ator tormi	ingle Nos 9	and 4. Connect
· ·				these wires to be mounted ou transformer to	a 125 oh t of the w	m 3 watt resi av. Use a 6	stor, which may
19X3	19 <b>Y</b> 3	E	No changes.				
19 <b>Y</b> 3	19X3	E	No changes.				

25BK5-26D6

SUB. CIRCUIT CHANGES NECESSARY TUBE PERF. P 25BK5 12BY7 Rewire as follows: to No. 7 No. 1 3 & 7 to to 1 & 3 or 9 No. 6 is heater tap. Do not use as tie point. Add 40 ohm 5 watt resistor in series with the filament. 19AQ5 G Change socket to 7 pin and rewire as follows: No. 1 to No. 5 3 & 7 to & 7 4 to 3 5 to 6 to to Remove and tape up any wires connected to Nos. 2 and 9. In parallel circuits add a 40 ohm 2 watt resistor in series with one of the filament leads. In series circuits, shunt a 120 ohm 5 watt resistor across the filament leads. 25L6GT E Change socket to octal and rewire as follows: No. 1 to No. 3 3 & 7 to to 2 4 5 to 6 8 to to Connections anchored to Nos. 2 and 9 may be placed on the free terminals of the octal socket. 25L6 25BK5 E Change socket to noval and rewire as follows: No. 2 on octal to No. 4 on noval 3 to 4 to 8 5 to 3 or 7 7 to 8 to 6 No changes, except to add a 90 ohm 2 watt resistor in series with one 26A6 12BA6 G heater lead. 26A7 12L8GT G No changes, except to add a 90 ohm 2 watt resistor in series with heater. Change socket to loctal and rewire as follows: 28D7 G to No. 7 on loctal No. 1 on octal to 3 4 2 to to 4 5 6 3 to to 1 to 8 ġ 5 to 26CG6 26A6 G No changes. Same as 26A6 to 12BA6. 12BA6 G No changes, except to add 90 ohm 2 watt resistor in series G 26D6 12BE6

with heater. (Parallel circuits only)

2807-5670	)	SUPPLEA	AENT—RECEIVING TUBE SUBSTITUTION GUIDE
TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
28D7	26A7	G	Change socket to octal and rewire as follows:  No. 1 on loctal to No. 6 on octal  to 3  to 5  to 4  to 4  to 4  5  to 8  to 8  to 2  7  to 1  8  to 7
28Z5	OZ4A/1003	G	This will work if the requirements for proper operation of the gas rectifier are met. Change socket to octal and rewire as follows:  Remove and tapeup any wires connected to Nos.  1, 4 and 8.  No. 3 on loctal to No. 3 on octal  6 to 5  7 to 8
50AX6G	6BY5	E	Rewire as follows:  Remove wires from Nos. 2 and 7 and connect them to a 330 ohm 10 watt resistor. Remove and tape up any wires on No. 1.  No. 4 to No. 1 3 to 4  The 6BY5 must be lit from a 6.3 volt 2.0 ampere filament transformer.
5590	6CF6	G	Parallel circuits only. No changes.
5591	6CF6	G	Parallel circuits only. No changes.
5670	6BK7	G	Parallel circuits only. Rewire as follows: Reverse No. 5 and No. 9  2 3 1 4

#### SUBSTITUTING PICTURE TUBES IN TV RECEIVERS

# 1. Connecting the External Conductive Tube Coating to Chassis

When a picture tube that does not have an external conductive coating is substituted for one that has the external coating, it is generally necessary to install a metal finger to make contact with the coating in order to connect it to the chassis. Sometimes this finger is attached to the deflection yoke support bracket. Ordinarily a tube that does not have an external coating has a 500- $\mu\mu$ f capacitor connected from the anode lead to the chassis inside the high-voltage cage. It is normally not necessary to remove this capacitor when substituting a tube that has the external conductive coating.

# 2. Installing a Capacitor from the Anode Lead to the Chassis

When a tube that does not have the external conductive coating is substituted for one that has the external conductive coating, it is often necessary to install a capacitor from the anode lead to the chassis. In the substitutions listed here we have repeated the same value of  $500~\mu\mu f$ . Ordinarily this will be satisfactory. In some cases this capacitor will not be necessary. In others best satisfaction may be had with capacitances as high

as 2,000  $\mu\mu$ f. This is according to individual cases and can be determined by trial. The most convenient location for this capacitor is inside the high-voltage cage.

#### 3. Dimensions

Before attempting any of the substitutions listed here, make sure the substitute tube will fit into the available space. In the magnetic types try to choose a substitute with a neck length similar to the original. Differences in face plate curvatures may make it necessary, in some substitutions listed, to change the mask.

#### 4. Change in Anode Connector

Either the ball-type or cavity-type anode connector is used on picture tubes. Instructions specify when a change is necessary.

#### 5. Replacement or Deletion of Ion Trap

It is necessary to replace the ion trap with the type required by the manufacturer of the substitute tube. Some tubes do not require an ion trap and are being substituted for others requiring either a single or dual ion trap. In these cases,

the instruction is "Remove ion trap." Other tubes requiring a single ion trap can be substituted for by installing a dual ion trap and vice versa. In these cases instructions are given. Some manufacturers of picture tubes are using a new type gun requiring a single ion trap in tubes that formerly used a gun requiring a dual ion trap. It is therefore important to check the individual manufacturer's specification on the substitute tube being used.

#### 6. Electrostatic and Self-Focus Tubes

When using electrostatic or self-focus tubes as substitutions for magnetically focused tubes, it is necessary to remove the focus coil from the neck of the tube and replace it with a magnetic centering device. The focus coil may be left in the receiver circuit-wise, in which case it should be mounted in the cabinet in some position where it magnetic field has no effect on the picture. It may be replaced with a choke or resistor. The picture tube socket may have to be changed when it is necessary to bring out a lead from the focus electrode on the picture tube base except in the case of self-focus or automatic focus types. This lead should be connected to a d-c voltage point in the set which gives best focus. The voltage required normally lies between 50 and 350 volts. Self-focus or automatic focus tubes have a special gun structure within the neck of the tube designed

to focus the tube automatically without the use of an external focus voltage.

# 7. Substituting Electrostatic or Automatic Focus Types with Magnetic Types

When replacing electrostatic focus types with magnetic focus types, discard the magnetic centering device and install a permanent magnet focusing device. This must be mounted on the yoke support with suitable metal brackets. It is practical to replace an electrostatic focus tube using high-focus voltage with a type using low-focus voltage or a self-focus type. When doing this, it is desirable to remove the focus voltage rectifier as a safety measure.

#### 8. Differences in the Face Plate

Differences in the face plate of the tube have little effect on whether or not they may be substituted. Dark-faced tubes give better contrast than white-faced tubes. Some tubes are frosted to decrease reflections and others have an aluminized back for better contrast and brightness. Aluminized tubes in some cases have higher anode voltage applied and this voltage should be reduced in accordance with manufacturers' specifications when other than aluminized tubes are substituted. When substituting aluminized tubes for white- or gray-faced tubes, sufficient voltage is usually available for satisfactory operation.

TUBE	SUB.	CHANGES NECESSARY
7HP4	7QP4	Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change anode connector to cavity type. Change ion trap to single.
7NP4	7WP4	Connect external conductive coating to chassis.
7QP4	7HP4	Change anode connector to ball type. Connect external conductive coating to chassis. Change ion trap to double.
7WP4	7NP4	No changes.
8AP4	8AP4A	No changes. Substitute has dark face.
8AP4A	8AP4	No changes. Substitute has white face.
10BP4	10BP4A	No changes. Substitute has dark face.
10BP4		
10BP4A	10CP4	Change anode connector to cavity type. Remove ion trap.
	10EP4	Change anode connector to cavity type.
	10FP4A 10FP4	Remove ion trap.
10CP4	10BP4 10BP4A	Only where 1" greater length is available. Change anode connector to ball type.
	10EP4	Only where 1" greater length is available. Change anode connector from ball to cavity type. Remove ion trap.
	10FP4 10FP4A	Change anode connector to cavity type.
10EP4	10BP4 10BP4A	Change anode connector from ball to cavity type.
	10CP4	Remove ion trap.
	10FP4 10FP4A	Change anode connector from ball to cavity type. Remove ion trap.
10FP4	10FP4A	No changes.
10FP4 10FP4A	10BP4 10BP4A	Install double ion trap.
	10CP4	Change anode connector to ball type.
	10EP4	Change anode connector from cavity to ball type. Install double ion trap.
10MP4	10MP4A	No changes.
10MP4A	10MP4	No changes.

## 12JP4-12QP4A SUPPLEMENT—RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	CHANGES NECESSARY
12JP4	12KP4 12KP4A	Connect external conductive coating to chassis. Change anode connector to cavity type.
12JP4	12LP4 12LP4A	Only where $1 \frac{1}{8}$ greater length is available. Change anode connector to cavity type. Install double ion trap.
	12QP4 12QP4A	Install double ion trap.
	12RP4	Install single ion trap.
	12TP4	Only where 1 $1/2$ " greater length is available. Change anode connector to cavity type. Install double ion trap.
	12VP4 12VP4A	Change anode connector to cavity type. Install double ion trap.
	12YP4	Only where 1" greater length is available. Change anode connector to cavity. Install single ion trap. Substitute is electrostatic focus. See No. 6 in picture tube article.
12KP4	12KP4A	No changes. Substitute has dark face.
12KP4 12KP4A	12JP4	Change anode connector to cavity type.
	12QP4 12QP4A 12RP4	Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change anode connector to ball. Install single ion trap.
	12TP4	Only where 1 1/2" greater length is available. Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Install double ion trap.
	12VP4 12VP4A	Install double ion trap.
	12YP4	Only where $1\ 1/2$ greater length is available. Install single ion trap. Substitute is electrostatic focus. See No. 6 in picture tube article.
12LP4	12LP4A	No changes. Substitute has dark face.
12LP4 12LP4A	12JP4	Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change anode connector to ball type. Remove ion trap.
	12KP4 12KP4A	Remove ion trap.
	12QP4 12QP4A 12RP4	Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change anode connector to ball type. Change ion trap to single.
	12VP4 12VP4A 12TP4	No changes.
	12YP4	Change ion trap to single. Substitute is electrostatic focus. See No. 6 in picture tube article.
12QP4	12QP4A	No changes. Substitute has dark face.
12QP4 12QP4A	12JP4	Remove ion trap.
	12KP4 12KP4A	Connect external conductive coating to chassis. Change anode connector to cavity type. Remove ion trap.

TUBE	SUB.	CHANGES NECESSARY
12QP4 12QP4A	12LP4 12LP4A	Only where 1 $1/2$ " greater length is available. Connect external conductive coating to chassis. Change anode connector to cavity type. Install ion trap.
	12RP4	No changes.
	12TP4	Only where 1 $1/2$ " greater length is available. Change anode connector to cavity type. Change ion trap to double.
	12VP4 12VP4A	Connect external conductive tube coating to chassis. Only where 1" greater length is available. Change anode connector to cavity type. Change ion trap to double.
	12YP4	Only where 1 1/2" greater length is available. Connect external tube coating to chassis. Change anode connector to cavity type. Substitute is electrostatic focus. See No. 6 in picture tube article.
12RP4	12JP4	Remove ion trap.
	12KP4 12KP4A	Connect external conductive tube coating to chassis. Change anode connector to cavity type. Remove ion trap.
	12LP4 12LP4A	Only where $1 \frac{1}{2}$ greater length is available. Connect external conductive tube coating to chassis. Change anode connector to cavity type. Change ion trap to double.
	12QP4 12QP4A	No changes.
	12TP4	Only where $1 \frac{1}{2}$ greater length is available. Change anode connector to cavity type. Change ion trap to double.
	12VP4 12VP4A	Only where 1 1/2" greater length is available. Connect external conductive coating to chassis. Change anode connector to cavity type. Change ion trap to double.
	12YP4	Only where 1 1/2" greater length is available. Change anode connector to cavity type. Substitute is electrostatic focus. See No. 6 in picture tube article.
12TP4	12JP4	Change anode connector to ball type. Remove ion trap.
	12KP4 12KP4A	Connect external conductive tube coating to chassis. Remove ion trap.
	12QP4 12QP4A	Change anode connector to ball type. Change ion trap to single.
	12RP4	
	12VP4 12VP4A	Connect external conductive tube coating to chassis.
	12YP4	Connect external conductive tube coating to chassis. Change ion trap to single. Substitute is electrostatic focus. See No. 6 in picture tube article.
12UP4	12UP4A	No changes. Substitute has dark face.
12UP4 12UP4A	12UP4B	Change to single ion trap.
12UP4B	12UP4 12UP4A	Change to double ion trap.
12VP4	12VP4A	No changes. Substitute has dark face.

# 14BP4-15CP4 SUPPLEMENT—RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	CHANGES NECESSARY
14BP4	14BP4A	No changes.
14BP4 14BP4A	14EP4 14CP4	No changes.
	14DP4	Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change ion trap to double.
	14FP4	Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis.
14CP4	14BP4 14BP4A 14EP4	No changes.
	14DP4	Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change ion trap to double.
	14FP4	Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis.
14DP4	14BP4 14BP4A 14CP4 14EP4	Connect external conductive coating to chassis. Change ion trap to single.
	14FP4	Change ion trap to single.
14EP4	14BP4 14BP4A 14CP4	No changes.
	14DP4	Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change ion trap to double.
	14FP4	Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis.
14FP4	14BP4 14BP4A 14CP4 14EP4	Connect external conductive coating to chassis.
	14DP4	Change ion trap to double.
15AP4	15CP4	Only where 1° greater length is available. Change anode connector to cavity type. Install double ion trap.
	15DP4	Change ion trap to single.
	16CP4	Only where 1" greater length is available. Change anode connector to cavity type. Install double ion trap.
	16LP4 16LP4A 16ZP4	Only where 2" greater length is available. Connect external conductive coating to chassis. Install double ion trap.
15CP4	15AP4	Change ion connector to ball type. Remove ion trap.
	15DP4	Change ion connector to ball type. Change ion trap to single.
	16CP4	No changes.
	16LP4 16LP4A 16ZP4	Only where 1" greater length is available. Connect external conductive tube coating to chassis.

•	30	10014 10014
TUBE	SUB.	CHANGES NECESSARY
15DP4	15AP4	Install single ion trap.
	15CP4 16CP4	Only where 1" greater length is available. Change anode connector to cavity type. Change ion trap to double.
	16LP4 16LP4A 16ZP4	Only where 2" greater length is available. Connect external conductive tube coating to chassis. Change anode connector to cavity type. Change ion trap to double.
16AP4	16AP4A	No changes.
16AP4A	16AP4	No changes.
16AP4 16AP4A	16AP4B	No changes.
16CP4	15AP4	Change anode connector to ball type. Remove ion trap.
	15CP4	No changes.
	15DP4	Change anode connector to ball type. Change ion trap to single.
	16LP4 16LP4A 16ZP4	Only where 1" greater length is available. Connect external conductive tube coating to chassis.
16DP4	16DP4A	No changes.
16DP4 16DP4A	16FP4	Change anode connector to ball type. Change ion trap to single.
	16HP4 16HP4A 16JP4 16JP4A	Connect external conductive tube coating to chassis.
	16MP4 16MP4A	Connect external conductive tube coating to chassis.
16EP4	16EP4A 16EP4B	No changes.
16EP4 16EP4A 16EP4B	16AP4 16AP4A 16AP4B	Only where $2-5/8$ ° additional length is available. Change ion trap to double.
16FP4	16HP4 16HP4A 16JP4 16JP4A	Only where 1" greater length is available. Connect external conductive tube coating to chassis. Change anode connector to cavity type. Change ion trap to double.
	16MP4 16MP4A	Only where 2" greater length is available. Connect external conductive tube coating to chassis. Change anode connector to cavity type. Change ion trap to double.
16GP4	16GP4A 16GP4B	No changes.
16HP4	16HP4A	No changes.
16HP4 16HP4A	16JP4 16JP4A	No changes.
	16MP4 16MP4A	Only where 1" greater length is available. No changes.
16JP4	16JP4A	No changes.
16JP4 16JP4A	16DP4 16DP4A	Connect 500- $\mu\mu$ f, 20 kv capacitor from anode to chassis.
	16FP4	Change anode connector to ball type. Change ion trap to single.
	16FP4A	40

#### 16JP4-16RP4 SUPPLEMENT—RECEIVING TUBE SUBSTITUTION GUIDE TUBE SUB. CHANGES NECESSARY 16JP4 16HP4 No changes. 16JP4A **16HP4A** 16MP4 Only where 1" greater length is available. **16MP4A** No changes. 16KP4 **16KP4A** No changes. 16KP4 16QP4 Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. **16KP4A** Change ion trap to double. **16RP4** No changes. 16TP4 No changes. 16UP4 Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. 16XP4 Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change ion trap to double. 16LP4 16LP4A No changes. Substitute has dark face. 16LP4 15AP4 Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. 16LP4A Change anode connector to all type. Remove ion trap. 15CP4 Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. 15DP4 Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change anode connector to ball type. Change ion trap to single. 16CP4 Connect 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. 16ZP4 No changes. 16MP4 16MP4A No changes. 16MP4 Same as 16JP4 substitutes. 16MP4A 16QP4 16KP4 Connect external conductive tube coating to chassis. Change ion trap to single. **16KP4A** 16RP4 Connect external conductive tube coating to chassis. Change ion trap to single. 16TP4 Connect external conductive tube coating to chassis. Change ion trap to single. 16UP4 Change ion trap to single. 16XP4 No changes. 16RP4 16KP4 No changes. **16KP4A** 16QP4 Change ion trap to double. 16TP4 No changes.

Change ion trap to double.

Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis.

Install 500- $\mu\mu$  f, 20-kv capacitor from anode to chassis.

16UP4

16XP4

TUBE	SUB.	CHANGES NECESSARY
16SP4	16SP4A	No changes.
16SP4A	16SP4	No changes.
16SP4 16SP4A	16VP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to ground. Change ion trap to single.
	16WP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis.
	16YP4	Change ion trap to single.
	16WP4A	No changes.
16TP4	16KP4 16KP4A	Only where 1" greater length is available. No changes.
	16QP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change ion trap to double.
	16RP4	Only where 1° greater length is available. No changes.
	16UP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis.
	16XP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change ion trap to double.
16UP4	16KP4 16KP4A	Connect external conductive tube coating to chassis.
	16QP4	Change ion trap to double.
	16RP4	Connect external conductive tube coating to chassis.
	16TP4	Connect external conductive tube coating to chassis.
	16XP4	Change ion trap to double.
16VP4	16SP4 16SP4A	Connect external conductive tube coating to chassis. Change ion trap to double.
	16WP4	Change ion trap to double.
	16WP4A	Connect external conductive tube coating to chassis. Change ion trap to double.
	16YP4	Connect external conductive tube coating to chassis.
16WP4	16SP4 16SP4A	Connect external conductive tube coating to chassis.
	16VF4	Change ion trap to single.
	16WP4A	Connect external conductive tube coating to chassis.
	16YP4	Connect external conductive tube coating to chassis. Change ion trap to single.
16WP4A	16SP4	No changes.
	16SP4A 16VP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change ion trap to single.
	16WP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis.
	16YP4	Change ion trap to single.

### 16XP4-17CP4A SUPPLEMENT—RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	CHANGES NECESSARY
16XP4	16KP4 16KP4A	Connect external conductive tube coating to chassis. Change ion trap to double.
	16QP4	No changes.
	16RP4	Connect external conductive tube coating to chassis. Change ion trap to single.
	16TP4	Connect external conductive tube coating to chassis. Change ion trap to single.
	16UP4	Change ion trap to single.
	16WP4A	Change ion trap to double.
16YP4	16SP4 16SP4A	Change ion trap to double.
	16VP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis.
	16WP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis. Change ion trap to double.
16ZP4		Same as 16LP4 substitutes.
17AP4	17BP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis.
	17BP4A 17BP4B 17BP4C	No changes.
	17JP4	No changes.
	17KP4	Substitute type is self-focus electrostatic. See No. 6 in picture tube article.
17BP4	17AP4	Connect external conductive tube coating to chassis.
	17BP4A 17BP4B 17BP4C	Connect external conductive tube coating to chassis.
	17JP4	Connect external conductive tube coating to chassis.
	17KP4	Substitute type is self-focus electrostatic. See No. 6 in picture tube article.
17BP4A	17BP4B 17BP4C	No changes.
17BP4A 17BP4B 17BP4C	17AP4	No changes.
	17BP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis.
	17JP4	No changes.
	17KP4	Substitute type is self-focus electrostatic. See No. 6 in picture tube article.
17CP4	17CP4A	No changes.
17CP4A	17CP4	No changes.

TUBE	SUB.	CHANGES NECESSARY
17FP4	17FP4A	No changes.
17FP4A	17FP4	No changes.
17FP4 17FP4A	17KP4	No changes. Focus voltage rectifier may be removed as a safety measure.
17HP4	17HP4A	No changes.
17HP4A	17HP4	No changes.
17HP4 17HP4A	17KP4	No changes.
	17RP4	No changes.
17JP4	17AP4	No changes.
	17BP4	Install 500- $\mu\mu$ f, 20-kv capacitor from anode to chassis.
	17BP4A 17BP4B 17BP4C	No changes.
	17KP4	Substitute is self-focus electrostatic. See No. 6 in picture tube article.
17KP4	17HP4 17HP4A	Original type is self-focus. Substitute is external control electrostatic focus. See No. 6 in picture tube article.
	17BP4 17BP4A	Original type is self-focus. Substitute is magnetic focus. See No. 7 in picture tube article.
17LP4	17LP4A	No changes.
17LP4 17LP4A	17SP4	No changes.
	17VP4	No changes.
17QP4	17SP4	Substitute is self-focus electrostatic See No. 6 in picture tube article.
	17UP4	No changes.
17RP4	17HP4 17HP4A	No changes.
	17KP4	No changes.
17SP4	17LP4 17LP4A	Substitute is external control electrostatic. See No. 6 in picture tube article.
17UP4	17QP4	No changes.
17UP4	17SP4	Substitute is self-focus electrostatic. See No. 6 in picture tube article.
17VP4	17LP4 17LP4A	No changes.
	17SP4	No changes.

## 19AP4-20CP4C SUPPLEMENT—RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	CHANGES NECESSARY
19AP4	19AP4A 19AP4B 19AP4C 19AP4D	No changes. Substitute has gray face. No changes. Substitute has gray frosted face. No changes. Substitute has gray aluminum face. No changes. Substitute has clear frosted face.
19AP4A 19AP4B 19AP4C 19AP4D		Refer to above.
19DP4	19DP4A	No changes. Substitute has gray face.
19DP4A	19DP4	No changes. Substitute has clear face.
19DP4 19DP4A	19FP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
	19GP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis. Change ion trap to single.
19EP4	19JP4	No changes.
19FP4	19DP4 19DP4A	Connect external conductive tube coating to chassis.
	19GP4	Change ion trap to single.
19GP4	19DP4 19DP4A	Connect external conductive tube coating to chassis. Change ion trap to double.
	19FP4	Change ion trap to double.
19JP4	19EP4	No changes.
20CP4	20CP4A	No changes.
	20CP4C	No changes. Substitute has treated face.
	20DP4	No changes.
	20DP4A	Connect external conductive tube coating to chassis.
	20JP4	Connect external conductive tube coating to chassis. Substitute is self-focus electrostatic. See No. 6 in picture tube article.
20CP4A	20CP4	Connect external conductive tube coating to chassis.
	20CP4C	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
	20DP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
	20DP4A	No changes.
	20JP4	Substitute is self-focus electrostatic. See No. 6 in picture tube article.
20CP4C	20CP4	No changes. Substitute has treated face.
	20CP4A	Connect external conductive tube coating to chassis
	20DP4	No changes.

20CP4C-2IFP4

TUBE	SUB.	CHANGES NECESSARY
20CP4C	20DP4A	Connect external conductive tube coating to chassis.
	20JP4	Substitute is self-focus electrostatic. See No. 6 in picture tube article.
20DP4	20CP4 20CP4C	No changes.
	20DP4A	Connect external conductive tube coating to chassis.
	20CP4A	Connect external conductive tube coating to chassis.
	20JP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
20DP4A	20CP4 20CP4C	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
	20DP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
	20JP4	Substitute is self-focus electrostatic. See No. 6 in picture tube article.
20FP4	20GP4	Connect external conductive tube coating to chassis.
	20JP4	No changes. Focus voltage rectifier may be removed as a safety measure.
20GP4	20FP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
	20JP4	No changes. Focus voltage rectifier may be removed as a safety measure.
20HP4	20HP4B	No changes. Substitute has treated face.
20HP4 20HP4B	20HP4A	Connect external conductive tube coating to chassis.
	20JP4	Connect external conductive tube coating to chassis.
	20LP4	Connect external conductive tube coating to chassis.
21EP4	21EP4A 21EP4B	Connect external conductive tube coating to chassis.
	21KP4	Substitute is self-focus electrostatic. See No. 6 in picture tube article.
	21KP4A	Connect external conductive tube coating to chassis. Substitute is self-focus electrostatic. See No. 6 in picture tube article.
21EP4A	21EP4B	No changes. Substitute is aluminized.
21EP4A 21EP4B	21KP4	Substitute is self-focus electrostatic. See No. 6 in picture tube article.
	21EP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
	21KP4A	Substitute is self-focus electrostatic. See No. 6 in picture tube article.
21FP4	21FP4A	Connect external conductive tube coating to chassis.
	21KP4	No changes.
	21KP4A	Connect external conductive tube coating to chassis.

2IFP4A-27RP	4 SUPPLEM	ENT—RECEIVING TUBE SUBSTITUTION GUIDE
TUBE	SUB.	CHANGES NECESSARY
21FP4A	21FP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
	21KP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
	21KP4A	No changes.
21KP4	21KP4A	Connect external conductive tube coating to chassis.
21KP4A	21KP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
21WP4	20CP4 20CP4C	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
	20CP4A	No changes.
	20DP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
	20DP4A	No changes.
	20JP4	Substitute is self-focus electrostatic. See No. 6 in picture tube article.
21ZP4	21ZP4A	Connect external conductive tube coating to chassis.
21ZP4A	21ZP4	Install 500- $\mu\mu$ f, 25-kv capacitor from anode to chassis.
22AP4	22AP4A	No changes.
22AP4A	22AP4	No changes.
24AP4	24AP4A 24AP4B	No changes.
24AP4B	24AP4 24AP4A	No changes.
27EP4	27GP4	No changes.
	27NP4	No changes.
	27RP4	No changes.
27GP4	27EP4	No changes.
	27NP4	Connect external conductive tube coating to chassis.
·	27RP4	Connect external conductive tube coating to chassis.
27NP4	27EP4	No changes.
	27GP4	No changes.
	27RP4	No changes.
27RP4	27EP4	No changes.
	27GP4	No changes.
	27NP4	No changes.

#### **CUMULATIVE INDEX**

The following index contains all the tubes listed in the RECEIVING TUBE SUBSTITUTION GUIDE-BOOK, including those given in the First and Second Supplements, for which substitutions are given. Where (0) precedes the page number, the substitution information is given on the page referred to in the original RECEIVING TUBE SUBSTITUTION GUIDEBOOK; where (1) precedes the page number, the substitution information is given on the page referred to in the First Supplement; and where (2) precedes the page number, the substitution information is given on the page referred to in the Second Supplement.

#### **RECEIVING TUBES**

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
00A	(0)33	1A7	(0) 34	1C7	(0)37
			(1) 14		
01A	(0) 33			1C8	(0) 37
		1A7	(0) 35		
0A2	(0) 33			1C21	(0) 37
	(0),00	1AB5	(0) 35	1001	(0)01
0A3	(0)33		(0)00	1D5	(0) 38
0.10	(1) 13	1AC5	(0) 35	120	(0,00
	(1) 13	IACS	(0)35	1D500	/ <b>0</b> \ 1
		1454	(0) 05	1D5GT	(2) 1
0A4	(0) 33	1AD4	(0) 35		
				1D7	(0)38
0B2	(0) 33	1AD5	(0) 35, 36		
				1D8	(0)38
0B3	(0) 33	1AE4	(0) 36	*	
			(1) 14	1E4	(0)38
0C3	(0) 33				
	• • •	1AF4	(0)36	1E5	(0)38
0D3	(0) 33		(0,00	,	(3/33
OD3	(0)00	1AF5	(0)36	1E7	(0) 38
0374	(0) 22	1711 0		12.	(0)00
0 <b>Y</b> 4	(0) 33		(1) 14	1E8	(0)38
	(0) 00	1-0	40.00	IEO	(0)30
0Y4G	(0) 33	1B3	(0) 36		
			(1) 14, 15	1F4	(0)38
<b>0Z4</b>	(0)33		(2)1		(1) 15
	(1) 13, 14				
		1B4	(0) 36	1F5	(0)38
0Z4A	(0) 33				(1) 15
		1B5	(0) 36		
1A3	(0)33		, ,	1F6	(0) 38
	(-,0-	1B7	(0) 36, 37	1.0	(0,00
1A4	(0) <b>3</b> 3	12.	(0,00,01	1F7	(0) 39
	(1) 14	1B8	(0) 37	***	(0)00
	(1)13	100	(0/31	104	(0) 20
1 4 4	(0) 04	1.00	(0) 0.0	1G4	(0)39
1A4	(0) 34	1C3	(0) 37		ias a a
				1G5	(0)39
1A5	(0)34	1C5	(0) 37		(1) 15
	(1) 14		(1) 15		
		1		1G6	(0) 39
				1 144	

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
1H4	(0)39	1N6	(0)44, 45	1W5	(0)48
	(1) 15			1	
		1P5	(0)45	1X2	(0)48
1H5	(0)39		(1) 18	· ·	(1) 19, 20
	(1)15				(2)1
	• •	1Q5	(0) 45		
1H6	(0)39		(1) 18	1X2A	(1) 20
	(5,55		(=, ==		
1J5	(0)39	1Q6	(0) 45		
	(1) 16		. ,	1Y2	(1) 20
	(-,	1R4/1294	(0) 45		• •
1J6	(0)39	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	(0) 10	1Z2	(0)48
100	(1)16	1R5	(0)45		
	(1)10	1100	(0)10		(1/20
1L4	(0)39	154	(0)46	2A3	(0)48
ILIT		10-2		22.0	
	(1) 16		(1)18, 19		(1)20
1L6	(0)40	105	(0)46	2A4G	(0) 49
1110		185	(0)46	ZATO	(0)40
	(1) 16		(1)19	0.45	(0) 40
47 4 4	(0) 40	100	(0) . 0	2A5	(0)48
1LA4	(0) 40	186	(0)46	0.4.0	(0) 40
	(1) 16	1		2A6	(0)48
		1SA6	(0)46		40. 40
1LA6	(0)40, 41		(1) 19	2A7	(0)48
11 D4	(0) 44	1070	(0) 40	07775	(0) 40
1LB4	(0)41	1SB6	(0)46	2B7S	(0)49
	(1)16	4574	(0) 10 17	oper	(0) 40
47.50	(0) (4	1T4	(0) 46, 47	2B25	(0)49
1LB6	(0)41		(1) 19	2074	(0) (0
45 ~~				2C4	(0)49
1LC5	(0)41, 42	1 <b>T</b> 5	(0)47		
			(1)19	2C21	(0)49
1LC6	(0)42				
		1T6	(0)47	2C22	(0)49
1LD5	(0) 42, 43				
		1U4	(0)47	2C51	(0)49
1LE3	(0)43	· ·	(1) 19		
	(1) 16, 17			2C52	(1) 20 (2) 1 (1) 20 (0) 48 (1) 20 (0) 48 (1) 20 (0) 48 (0) 48 (0) 48 (0) 49 (0) 40 (0)
		1U5	(0)47		
1LG5	(0)43			2D21	(0)49
	(1) 17	1U6	(0)47		
				2E5	(0) 49
1L H4	(0)43	1V	(0)47		
	(1) 17, 18	1	(1) 19	2E26	(0)49
			• • • = :		
1LN5	(0)43,44	1V2	(0) 47	2E30	(0)49
· <del>-</del>	(1)18		<b>.</b> - • = •		• • =- •
	\-/ <b>-</b> 0	1V5	(0) 47	2E31	(0)49
1N5	(0)44		(0) 41		(-/
	(1)18	1W4	(0)48	2E32	(0)49
	(1)10	1112	(1)19	2002	(0/30
		1	(1)13		

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
2E35	(0) 49	3LE4	(0) 52	5Y3	(0) 55
,			(1) 21		(2) 1
2E36	(0)49				
		3LF4	(0) 52	5Y4	(0) 55
2E41	(0) 49		(1)21		(2) 1
2E42	(0)49	3Q4	(0)52	5Z3	(0) 55
4C42	(0)49	264	(0)32	323	(2) 1
2G5	(0) 49	3 <b>Q</b> 5	(0) 52		
				5Z4	(0) 56
2G21	(0) 50	3Q5	(0) 53		(2) 1
2G22	(0) 50	354	(0) 53	6A3	(0) 56
2G22	(0)50	304	(0)00	0.20	(0)00
2S/4S	(0) 50	3V4	(0) 53	6A4	(0) 56
2V3	(0)50	4A6	(0)53	6A4/LA	(0) 56
2W3	(0) 50	5A6	(0) 53	6A5	(0) 56
2113	(0)30	3710	(0)00	0.20	(0,00
2X2/879	(0) 50	5AW4	(2) 1	6A6	(0) 56
	•				(1) 21
2 <b>Y</b> 2	(0)50	5AX4	(0) 53		
				6A7	(0) 56, 57
2Z2/G84	(0) 50	5AZ4	(0) 53		(1)21
	(0) 50		(2) 1	649	(O) 57
3A4	(0)50	57,4677	(O) EO	6A8	(0) 57
	(O) 5 O	5R4GY	(0) 53		(1) 21, 22
3A5	(0)50		(2) 1	6AB4	(0)57, 58
0 A 0 C TT	(O) EO	ETD4	(0) 53	OADT	(0) 51, 56 (2) 1
3A8GT	(0)50	5T4		6.2	(2) 1
3B4	(0) 50		(2) 1	6AB5/6N5	(0) 58
3174	(0)30	5T4	(0)54	0.150,0110	(0)00
3125	(0) 50, 51	314	(2) 1	6AB6	(0) 58
3B5	(1) 20		(2) 1		(0,00
	(1)20	5U4	(0) 54	6AB7/1853	(0) 58
3B7	(0) 51	001	(2) 1		
<b>.</b>	(0)01		<b>\_/</b> _	6AC5G	(0) 58
3B7/1291	(0) 51	5V4	(0)54		5 T
			(2) 1	6AC5GT	(0) 59
3C5	(0) 51				
		5W4	(0) 54	6AC6	(0) 59
3C6	(0)51		(2) 1		
				6AC7	(0) 59
3D6/1299	(0) 51	5X3	(0) 54	<u>.</u>	
				6AC7/1852	(0)59
3E5	(0) 51	5X4	(0) 54		
			(2) 1	6AD4	(0) 59
3E6	(0) 51			6AD5	(0) 59

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
6AD6	(0) 59	6AK7	(0) 62	6AT6	(0)64,65
6AD7	(0) 60	6AK8	(2) 3	6AU5	(0) 65
•	(1)22		(-)		(1) 23
	(1)22	6AL5	(0) 62		(2/20
6AE5	(0) 60	0.113	(1)23	6AU6	(0) 65, 143
OAES			(1)23	OAU6	
	(1)22		(0) 00		(1)24
		6AL6	(0) 62		
6AE6	(0) 60		(1) 23	6AV5	(0)65
CATA	(2) 1	6AL7	(0) 62	6AV6	(0) 65
6AF4	(2) 1	OVTI	(0) 02	OAVO	
OATE	(0) 00	0.634	(O) O		(2) 3
6AF5	(0) 60	6AM4	(2) 3		(0) ==
	(1) 22			6AW7	(0) 65
		6AM5	(0) 62		
6AF6	(0) 60		(2) 3	6AX4	(1) 24
6AF7	(0) 60	6AM6	(0) 62, 63	6AX5	(0) 65
6AG5	(0) 60	6AN4	(2) 3	6AX6	(0) 65, 66
	(1) 22		\-, <del>-</del>		(=, ==,
	(2) 1	6AN5	(0) 63	6B4	(0) 66
	(4) 1	UALIO	(0)00	) JD3	(0)00
6AG6G	(0) 60	6AN6	(0) 63	6B5	(0)66
6AG7	(0)60	6AN7	(0) 63	6B6	(0)66
6AH4	(2) 2	6AQ5	(0) 63	6B7	(0) 67
	<b>\-</b> / -		(1) 23		
6AH5	(0)61	. [	(2) 3	6B8	(0) 67
0.1110	(0/01		(2)	323	(0,01
6AH6	(0) 61, 143	6AQ6	(0) 63	6BA5	(0) 67
	(2) 2	3-1-40	(1)23	32-3	\-/ <del>-</del> '
	(4) 4		(1/20	6BA6	(0) 67
CAUT	(0) 61	6407	(0) 62	ODAU	
6AH7	(0) 61	6AQ7	(0) 63		(1) 24
0474	(O) O		(0) 04		(2) 3
6AJ4	(2) 2	6AR5	(0) 64		(0) 07
			400 0 0	6BA7	(0) 67
6AJ5	(0) 61	6AR6	(0) 64		
	(2) 2		(1) 23	6BC5	(0) 67
					(1) 24
6AJ7	(0) 62	6AR7	(0) 64		(2) 3
6AJ8	(2) 2	6AS5	(0) 64	6BC7	(0) 68
<i>-</i>	\ <b>-</b> /. <b>-</b>	0.100	(2) 3	325.	(0,00
6AK5	(0) 62		(4) 0	6BD5	(0) 69
OVIVO		6450		פתפס	(0)68
	(1) 22	6AS6	(0) 64	277.2	(0) 00
	(2) 2			6BD6	(0) 68
		6AS7G	(0)64		
6AK6	(0) 62			6BD7	(0) 68
	(2) 3	1			

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
6BE6	(0) 68	6BY5	(0) 69	6E5	(0) 73
			(2) 4		
6BF5	(0) 68		\-, -	o To C	(O) <b>50</b>
022 0	,,,,,,	6BY7	(2) 5	6 <b>E</b> 6	(0) 73
6BF6	(0) 68	ODII	(2)		(1) 25
ODI O	(0)08	6BZ7	(2) 5		•
en El	(0) 00	0521	(2) 5	6E7	(0) 73
6BF7	(0)68		10) 00 50	· - ·	(0) (0)
		6C4	(0) 69, 70		
6BG6	(0) 68		(2) 5	<b>6E8</b>	(0) 73
	(1) 24				
		6C5	(0) 70	6F4	(0) 73
6BG7	(0) 68		(1) 24	<b>U</b>	(5) 15
			(2) 5		
<b>6BH6</b>	(0) 68			6F5	(0)73,74
	(1) 24	6C6	(0) 70, 71, 143		
	\2/21		(0,10,12,20	6 <b>F</b> 6	(0)74, 143
en te	(0) 69 60	6C7	(0) 71	02 0	(1) 25
6BJ6	(0) 68, 69	001	(0) 71		(1/40
	(2) 3		(O) 84 TO		
		6C8	(0) 71, 72	6F7	(0) 74
6BK5	(2) 4				(1) 25
		6CB6	(0) 72		• • •
6BK6	(0) 69		(1) 25		40.
	ļ		(2) 5	6F8	(0) 74
6BK7	(2) 4				(1) 25
	\-'	6CD6	(0) 72		
6BL7	(1) 24	3020	(1) 25	6G5	(0) 75
ODLI	1.		(1)20		
	(2) 4	COEC	(0) (	ene	/A\ 75
		6CF6	(2) 6	6 <b>G6</b>	(0)75
6BM5	(2) 4				
	1.	6CG6	(1) 25	6H4	(0) 75
6BN6	(0) 69		(2) 5, 6		
				6H5	(0) 75
6BN7	(1) 24	6CH6	(2) 6		
		•		6176	/0\7E
6BQ6	(0) 69	6CK6	(2) 6	6H6	(0) 75
O-Delo	(2) 4	00170	(2)		
	(4) 3	ect e	(2) 6, 7	6H8	(0) 75
0005	(1) 04	6CL6	(4) 0, 1		
6BQ7	(1) 24	· · · · · · · · · · · · · · · · · · ·	(0) -	4=4	/A\ == ==
	(2) 4	6CS6	(2) 7	6 <b>J</b> 4	(0) 75, 76
	·				
6BT6	(0) 69	6CU6	(2) 7	6 <b>J</b> 5	(0)76
	(2) 4				(1)25
		6D4	(0) 72		(2) 7
6BU6	(0) 69				
<b>5</b> _ 5 <b>0</b>		6D6	(0) 72	<b>6</b> J6	(0)76
6BW6	(2) 4	020	(0).2	•••	(1)26
ODWO	(4) 1	eng	(0) 72		(1/20
	(0) 1	6D7	(0) 72	A78	(A) 20 EE 140
A-77-5	(2) 4	-= -	(0) =0	6 <b>J</b> 7	(0) 76, 77, 143
6BX6		6D8	(0) 72		
		ODO	(0)		
6BX6 6BX7	(2) 4	020		<b>6J8</b>	(0) 77, 78 (1) 26

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
6K4	(0)78	<b>ଦେ</b> 6	(0) 82	6SK7	(0) 87, 88
					(1)29
6K5	(0) 78	<b>ଦେ</b> 7	(0) 82, 83	egt p	(0) 99
			(1) 27	6SL7	(0) 88
6K6	(0) 78, 79				(1)29
	(1) 26	6R4	(0) 83	6SN7	(0) 88, 89
			(2) 8		(1)29
6K7	(0) 79, 80				(2) 8
		6R6	(0) 83		· · ·
6K8	(0) 80			6SQ7	(0)89, 90
	(1) 26	6R7	(0) 83		(1) 29
			(1)27		
6L4	(0) 80			6SR7	(0)90
		6R8	(0) 83		(1)30
6L5	(0) 80		(1) 27		• •
	(1) 26		• •	6SS7	(0) 90
	• •	<b>6</b> S4	(1) 27		• •
6L6	(0) 80, 81	<del></del>	•=•=•	6ST7	(0)91
	(1) 26, 27	6S6	(0) 84		
	\-,-0,	<del></del>	(-, - <u>-</u>	6SU7	(0)91
6L7	(0) 81	6SA7	(0) 84		(0)01
J~1	(0)01	0221	(1) 28	6SV7	(0) 91
6M5	(0) 81		(1)20	0577	(0)31
01410	(2) 7	687	(0)84	6SZ7	(0) 91
	(4) 1	001	(0)0%	0521	(0) 31
6M6G	(0) 81	6S8	(1) 27	6T4	(2) 8
6M7G	(0)81	6S8GT	(2) 8	<b>6T5</b>	(0) 91
6M8GT	(0) 81	6SB7Y	(0) 84	<b>6T6</b>	(0)91
	, ,		(1) 28		•-•-
6N4	(0)81		<b>\-,</b>	6T7	(0)91
	\-/	6SC7	(0) 84, 85		(0/02
6N5	(0) 81	J	(1) 28	6T8	(0) 91, 143
	\-/		(-/-0		(1)30
6N6	(0) 81	6SD7	(0) 85		(2) 8
0210		(A) 1	(0,00		(2) 0
6N7	(0)81,82	6SE7	(0) 85	6U3	(2) 8
6N8	(0) 82	6SF5	(0) 85, 86	6U4	(0) 91
			- - -		(1)30
6P5	(0) 82	6SF7	(0) 86		• •
	(1) 27			6U5/6G5	(0) 91
		6SG7	(0) 86		(1)30
6P7	(0) 82	· •	(1) 28		\-, <del>-</del> -
	(1) 27		•=• <del>==</del>	6U6	(0) 91, 92
	, - , - <del>.</del>	6SH7	(0) 86		(1)30
6P8G	(0)82	·	(1) 29		(2),00
	(5,52		\-/=0	6U7	(0)92
6Q4	(2) 8	6SJ7	(0) 86, 87		(0)34
vųı	(2) 0	0.50 (	(1) 29	6U8	(1)30
6Q5G	(0) 82		(1/40	1 000	(2) 8

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
6V3	(2) 9	7A4	(0) 97	7C7	(0) 102, 103
		1 .	(1)31		(1)33
6V4	(0) 92	1 *			
	•	7A5	(0) 97	7D7	(0) 103
6V5GT	(2) 9		, <b>\-/-</b> -		(0) 100
ovodi	(2) 0	7A6	(0) 97	7E5	(0) 103
6V6	(0) 00 00	IAU	(0)31	160	(0)103
040	(0) 92, 93	747	(0) 07 00	<b>5</b> 500	(0) 100
	(1)30	7A7	(0) 97, 98	<b>7</b> E6	(0) 103
			(1)31, 32		(1)33
6V7	(0)93				
		7A8	(0) 98	7E7	(0) 103
6V8	(0) 30, 31		(1) 32		
				7F7	(0) 103
6W4	(0)93	7AB7	(0) 98, 99		
	(1)31			7F8	(0) 104
	\=/.==	7AD7	(0) 99		(1) 33
6W5	(0) 93	,,	(0)00		(2),00
UND	(0) 33	7AF7	(0) 99	7G7	(0) 104
OWA	(0) 00	(Ar')	• •	101	(0) 104
6W6	(0) 93		(1)32		
	(1)31			7G7/1232	(0) 104
	(2) 9	7AG7	(0)99	•	
	•			7G8	(1)33
6W7	(0) 93, 9 <del>4</del>	7AH7	(0) 99		(1),00
				7H7	(0) 104
6X4	(0)94	7AJ7	(0) 99	(D)	(0) 104
-	(0,02		• •	7J7	(0) 104
6X5	(0) 94, 95	7AK7	(0) 99		(1)33
0210	(0)01, 00	11221	(0,00		(1/00
6X6G	(0) 95	7B4	(0) 100	7K7	(0) 105
OAUG	(0)33	1124		IX.	(0) 103
ATT 0	(1) 01		(1)32	<b></b>	(0) 105
6X8	(1)31		(0) 100	7L7	(0) 105
	(2) 9	7B5	(0) 100		
	•		(1)32	7N7	(0) 105
6Y3G	(0) 95				(1)33,34
		7B6	(0) 100		
6Y5	(0) 95		(1)32	7Q7	(0) 105
		,			(1)34
6Y6	(0) 95	7B7	(0) 100, 101		
	• • • <del>•</del>		(1) 32	7R7	(0) 105
6Y7	(0)96		\=/.==		(1)34
OTI	(0)30	7B8	(0) 101		(1)01
C37EC	70) 144	150		707	(0) 10E
6Y7G	(0) 144		(1)32	787	(0) 105
	10) 6 -		'(A) 4 A A		(1)34
6 <b>Z</b> 3	(0) 96	7C4	(0) 101		
				7T7	(0) 105, 106
6 <b>Z</b> 4	(0) 96	7C5	(0) 102		
			(1) 32	777	(0) 106
6 <b>Z</b> 5	(0) 96				
- <del>-</del>	• • •	7C6	(0) 102	7W7	(0) 106
6 <b>Z</b> 7	(0) 96		(1)33		(=, = 0
٠.	(0,00		(1/00	776	(0) 106
6ZY5	(0)96	1		7X6	(0) 106

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
7X7	(0) 106	12AX4	(1)36	12H6	(0) 110
7Y4	(0) 106	12AX7	(0) 108	12J <b>5</b>	(0) 110
	(1) 34		(1)36		• •
	(2/52		(1)00	12J7	(0)110
<b>7</b> Z4	(0) 106	12AY7	(0) 108, 109		
	(1)34	12.11	(1)36	12K7	(0)110, 111
	(1)54		(1).50	1211	(1)36
10	(0) 106	12AZ7	(1) 26		(1),00
10	(0)100	12/12/	(1)36	12K8	(0)111
10Y	(0) 106	1004	(2) 0	12110	(1)36
101	(0) 106	12B4	(2) 9		(1),30
12A	(0) 100	10004	(0) 100	12L8	(0) 111
120	(0) 106	12B6M	(0) 109	12110	(0)111
12A4	(2) 9	1007	(0) 100	12Q7	(0) 111
1407	(4) 5	12B7	(0) 109	120(1	(1)36
12A5	(0) 107	100000	(0) 100		(1/30
12A3	(0) 107	12B8GT	(0) 109	12S8	(2) 9
1040	(0) 105	10714	(0) 100	1200	(2) 9
12A6	(0) 107	12BA6	(0) 109	10015	(0) 111 110
	(1)34		(1)36	12SA7	(0)111, 112
					(1)36
12A8	(0) 107	12BA7	(0) 109		
	(1)35			12SC7	(0) 112
		12BD6	(0) 109		(1)36
12AH7	(0) 107				
	(1)35	12BE6	(0) 109	12SF5	(0) 113
			*		<b>(1) 36</b>
12AH8	(2) 9	12BF6	(0) 109	•	
				12SF7	(0)113
12AK7	(2) 9	12BH7	(0) 109		
			(1)36	12SG7	(0) 113
12AL5	(0) 107				(1)37
		12BK6	(0) 109		
12AT6	(0) 108			12SH7	(0) 113
	(1)35	12BN6	(1)36		(1)37
	(2) 9		,- <i>p</i>		
	<b>\=</b>	12BT6	(0) 109	12SJ7	(0) 113
12AT7	(0) 108, 143		<b>\-/</b> ===		(1)37
	(1) 35	12BU6	(0) 110		
	\-,		\-/ <del></del>	12SK7	(0) 113, 114
12AU6	(0) 108	12BY7	(2) 9		(1)37
	(-,	1001	\ <del>-</del> / •		(2) 10
12AU7	(0) 108	12BZ7	(2) 9	er i i	•=• <del>-</del> -
	(1)35	*******	(-)	12SL7	(0) 114
	\-/.50	12C8	(0) 110	,	(1)37
12AV6	(0) 108	1200	(0) 110		N-7 1
T U	(0) 100	12E5	(0) 110	12SN7	(0)114
12AV7	(0) 108	1 220	(0)110	24041	(1)37
TW17 A	(1)35	12F5	(0) 110		(1),01
	(1)99	1470	(0) 110	128Q7	(0) 114, 115
12AW6	(0) 108	12G7G	(0) 110	2234.	(1)37

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
12SR7	(0) 115 (1) 38	14F7	(0) 117 (1) 39	19X3	(2) 10
				19Y3	(2)10
12887	(2)10	14F8	(0) 117		
12401	(2)10		(1)39	20	(0)118
12SW7	(0) 115 (1) 38	14H7	(0) 117	20J8	(0)118
		14J7	(0) 117	21A7	(0)118
12SX7	(0) 115		(1)39	22	(0) 118
	(0) 445	14N7	(0) 117		(0)116
12SY7	(0) 115 (1) 38	2211	(1)39, 40	24A	(0) 118
	(-/	14Q7	(0) 117	25A6	(0) 118, 119
12V6	(2)10	1401	(1)40	25/10	(γ)110, 119
				25A7	(0) 119
12X4	(2) 10	14R7	(0) 117		
1072	(0) 115	1487	(0) 117	25AC5	(0) 119
12 <b>Z</b> 3	(0) 115 (1) 38	1401	(0)111	25AV5	(0) 119
	(=,=0	14V7	(0) 117		(0,220
<b>12Z5</b>	(0) 115			25B5	(0) 119
1444	(0) 115	14W7	(0) 117	0570	
14A4	(0) 115	14X7	(2) 10	25B6	(0) 119
14A5	(0) 116		(2)10	25B8GT	(0) 119
		14Y4	(0) 117		
14A7	(1)38	15	(0) 117 110	25BK5	(2) 11
14A7/12B7	(0)116	15	(0) 117, 118	25BQ6	(0) 119
14M (/ 12D )	(0)110	17	(0) 118	201100	(0)113
14AF7	(1)38		. ,	25C6	(0) 119
		18	(0) 118		
14AF7/XXI	0 (0) 116		(0) 110	25D8GT	(0) 120
14B6	(0) 116	19	(0) 118	25L6	(0) 120
UTDO	(1)38	19AQ5	(2) 10	2320	(2) 11
1400	(0) 116	19BG6	(0) 118	25N6	/0\ 100
14B8	(0) 116	0Dae1	(0)110	29116	(0) 120 (1) 40
14C5	(0) 116	19C8	(0) 118		\-/ - <del>-</del>
			(1)40	<b>25</b> S	(0) 120
14C7	(0) 116	4075	(0) 10	4 1.	40) 400
	(1)39	<b>19J</b> 6	(2) 10	25W4	(0) 120
14E6	(0) 116	<b>19T8</b>	(0) 118	25X6	(0) 120
	(1) 39		(1)40		
	(0) 445 - 555	40000	(4) 40	25Y4	(0) 120
14E7	(0) 116, 117	19V8	(1)40	OEWE	/0\ 120
				25Y5	(0) 120

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
25Z3	(0)120	35A5	(0) 122, 123	4525	(0)128 (1)42
25Z4	(0) 120	35B5	(0) 123	  -  -	(1)12
	• • • •			46	(0)128
<b>25Z</b> 5	(0) 120, 121	35C5	(0)123		
			(0) 104	47	(0)128
25Z6	(0) 121	35L6	(0) 124	48	<b>(0)120</b>
26	(0) 121		(1)41	40	(0)129
20		35W4	(0) 124	49	(0)129
26A6	(0) 121				
	(2)11	35Y4	(0) 124, 125	50	(0)129
	(0) 101		(1)41	5045	. (0) 100
26A7	(0) 121 (2) 11	35Z3	(0) 125	50A5	(0)129 (1)42
	• •	3043	(1)41		(1/24
26BK6	(0) 121		\-/	50AX6	(0)129
2222	(0) 101	35Z4	(0) 125		
26C6	(0) 121	,	(1)41	50AX6G	(2)12
26CG6	(2)11	3525	(0)125, 126	50B5	(0) 129
	<u>-,</u>	3045	(1)41, 42	GAVG	(0)129 $(1)42$
26D6	(0) 121		\-/; <del></del>		(-/
	(2)11	35Z6	(0)126	50C5	(0) 129
26Z5W	(1)40				(1)42
4040W	(1)40	35/51	(0) 126	5000	(0) 100
27	(0) 121		(1)41	50C6	(0) 129 (1) 42, 43
		36	(0)126		(4/34, 30
28D7	(0) 122	:		50L6	(0)129
	(2)12	37	(0)126		(1)43
28D7W	(0) 122	20	(0) 19¢	ENVA	(0) 120
• • •		38	(0) 126	50X6	(0) 130
<b>28Z</b> 5	(0) 122	39/44	(0) 126	50 <b>Y</b> 6	(0) 130
	(2) 12				(1)43
30	(0) 122	40	(0)126		
3U	(U) 122	40775	(1) 40	50Y7	(0)130
31	(0) 122	40Z5	(1)42	50Z6	(0)130
		41	(0) 127	0020	(0) 4,00
32	(0) 122			50 <b>Z</b> 7	(0)130
201 17	<b>(0) 199</b>	42	(0) 127, 128		
32L7	(0) 122	43	(0) 128	EF50	(0) 130
33	(0) 122		\-,- <del>-</del>	52	(0) 130
•	(1)40	45	(0)128	52	(0)130
			(1)42	VT52	(0)130
34	(0) 122	4570	<b>(0) 100</b>		
	(1)41	45Z3	(0) 128	53	(0)130
				55	(0) 130

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
55S	(0)130	84/6Z4	(0) 135 (1) 43	958A	(0)138
56	(0) 131	85	(0)135, 136	959	(0) 138
56AS	(0) 131	85AS	(0) 136	FM1000	(0) 138
56S	(0) 131	89	(0) 136	1005/CK1005	(0)138
57	(0) 131 (1) 43		(1)43	CK1013	(0)138
57AS	(0) 131	99V	(0)136	1201	(0) 138
5 <b>7</b> S	(0) 131	Х99	(0)136	1203	(0) 138
58	(0) 131	117L7	(0) 136	1204	(0)138
<b>J</b>	(1)43	117L7/M7	(0)136	1206	(0) 138
58AS	(0) 131	117M7	(0)136	1221	(0) 138
58S	(0)131	117N7	(0)136, 137 (1)43	1223	(0) 138
59	(0) 131	117P7	(0) 137	1229	(0)138
70A7	(0) 131			1230	(0) 138
70 <b>L</b> 7	(0) 131, 132	117Z3	(0) 137	1231	(0) 138
71A	(0) 132	11724	(0) 137	1232	(0)138
	(1)43	117Z6	(0)137	1247	(0)138
75	(0) 132	182B/482B	(0) 137	1265	(0) 138
76	(0) 132, 133	183/483	(0) 137	1266	(0)138
77	(0) 133	210T	(0) 137	1267	(0)138
78	(0) 133, 134	485	(0) 137	1273	(0) 138
79	(0)134, 144	807	(1)43, 44	1274	(0) 138, 139
80	(0) 134	864	(0)137	1275	(0)139
81	(0) 134	950	(0) 137	1276	(0)139
82	(0) 134	954	(0) 137	1280	(0) 139
83	(0) 134	955	(0) 138	1284	(0) 139
83V	(0) 135	956	(0)138	1291	(0) 139
84	(0) 135	957	(0) 138	1201	(0) 103

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
1293	(0) 139	5643	(0) 140	5744	(0)141
1294	(0)139	5646	(0) 140	5783	(0) 141
1299	(0) 139	5647	(0) 140	5784	(0)141
1603	(0)144	5654	(0)140	5785	(0) 141
1611	(0) 144	5670	(0) 140	5787	(0) 141
1612	(0) 139		(2)12	5812	(0) 141
1014	(0) 100	5672	(0) 140		•
1614	(0) 139 (1) 44	5.050	(0) 140	5823	(0) 141
	(-/	5676	(0)140	5824	(0) 141
1619	(0) 139	5677	(0) 140	0021	
1620	(0) 130			5840	(0) 141
1040	(0) 139	5678	(0) 140	5045	(0) 141
1626	(0) 139	5679	(0) 140	5847	(0) 141
			(-/	5879	(0) 141
1629	(0) 139	5686	(0) 140		
1634	(0) 139	5.007	(0) 140	5881	(1)44
_ <b></b>	\-, <u>-</u> ,	5687	(0)140	5896	(0) 141
1644	(0) 139	5691	(0) 140	3030	(0)111
1654	(0) 120			5897	(0) 141
1654	(0) 139	5692	(0) 141		(0) 1 40
2050	(0) 139	5693	(0) 141	5898	(0)142
		0000	(0/11	5899	(0) 142
2051	(0) 139	5694	(0) 141		
5517	(0) 139	E 007	(0)141	5900	(0)142
JUL 1	(0) 100	5697	(0) 141	5901	(0) 142
5517/CK1013	(0) 140	5702	(0) 141	2901	(0) 132
5500	(0) 140			5910	(0) 142
5590	(0) 140 (2) 12	5703	(0) 141		(0) 4.45
	(2/22	5704	(0) 141	5915	(0) 142
5591	(0) 140		\-/ <del>-</del>	5931	(0) 142
	(2)12	5718	(0) 141		
5608-A	(0) 140	5710	(0) 141	5932	(0) 142
J000 11	(0) 110	5719	(0) 141	7000	(0) 144
5618	(0) 140	5722	(0) 141	1000	(0) 133
E00E	(0) 140		(0) 1.15	7700	(0) 144
5635	(0) 140	5725	(0) 141		(0) 1.40
5636	(0) 140	5726	(0)141	9001	(0) 142
				9002	(0) 142
5642	(1)44	5731	(0) 141	L	• · • · · · · · · · · · · · · · · · · ·

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE	
9003	(0) 142	9006	(0) 142	XXD	(1)44	
9004	(0) 142	KT66	(1)43	XXFM	(0) 142	
9005	(0) 142	X6030	(0) 142	XXL	(0) 142	

#### PICTURE TUBES

	<del></del>				
7HP4	(2) 15	12JP4	(2)16	14BP4A	(2) 18
7NP4	(2)15	12KP4	(2) 16	14CP4	(2) 18
7QP4	(2) 15	12KP4A	(2)16	14DP4	(2)18
7WP4	(2) 15	12LP4	(2)16	14EP4	(2)18
8AP4	(2) 15	12LP4A	(2) 16	14FP4	(2) 18
8AP4A	(2) 15	12QP4	(2) 16, 17	15AP4	(2)18
10BP4	(2) 15	12QP4A	(2) 16, 17	15CP4	(2)18
10BP4A	(2) 15	12RP4	(2)17	15DP4	(2)19
10CP4	(2) 15	12TP4	(2) 17	16AP4	(2)19
10EP4	(2) 15	12UP4	(2) 17	16AP4A	(2)19
10FP4	(2) 15	12UP4A	(2) 17	16CP4	(2) 19
10FP4A	(2) 15	12UP4B	(2) 17	16DP4	(2) 19
10MP4	(2)15	12VP4	(2)17	16DP4A	(2) 19
10MP4A	(2) 15	14BP4	(2)18	16EP4	(2) 19

16EP4A       (2) 19       17AP4       (2) 22       19DP4A       (2) 24         16EP4B       (2) 19       17BP4       (2) 22       19EP4       (2) 24         16FP4       (2) 19       17BP4A       (2) 22       19FP4       (2) 24         16GP4       (2) 19       17BP4B       (2) 22       19JP4       (2) 24         16HP4A       (2) 19       17CP4       (2) 22       20CP4       (2) 24         16HP4A       (2) 19, 20       17CP4A       (2) 22       20CP4A       (2) 24         16HP4A       (2) 19, 20       17FP4       (2) 23       20CP4C       (2) 24, 25         16KP4       (2) 20       17FP4A       (2) 23       20DP4       (2) 25         16KP4A       (2) 20       17HP4A       (2) 23       20DP4       (2) 25         16LP4       (2) 20       17HP4A       (2) 23       20FP4       (2) 25         16LP4       (2) 20       17HP4A       (2) 23       20FP4       (2) 25         16MP4       (2) 20       17KP4       (2) 23       20HP4       (2) 25         16MP4A       (2) 20       17LP4A       (2) 23       20HP4       (2) 25         16MP4       (2) 20       17LP4A	TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
16FP4       (2) 19       17EP4A       (2) 22       19FP4       (2) 24         16GP4       (2) 19       17EP4B       (2) 22       19GP4       (2) 24         16HP4       (2) 19       17EP4C       (2) 22       19JP4       (2) 24         16HP4A       (2) 19       17CP4       (2) 22       20CP4A       (2) 24         16JP4A       (2) 19, 20       17EP4A       (2) 23       20CP4C       (2) 24, 25         16KP4A       (2) 19, 20       17EP4A       (2) 23       20DP4C       (2) 24, 25         16KP4A       (2) 20       17EP4A       (2) 23       20DP4A       (2) 25         16KP4A       (2) 20       17HP4A       (2) 23       20FP4       (2) 25         16LP4       (2) 20       17HP4A       (2) 23       20FP4       (2) 25         16MP4A       (2) 20       17KP4       (2) 23       20HP4       (2) 25         16MP4A       (2) 20       17LP4       (2) 23       20HP4B       (2) 25         16MP4A       (2) 20       17LP4       (2) 23       21EP4       (2) 25         16MP4       (2) 20       17CP4       (2) 23       21EP4       (2) 25         16SP4       (2) 21       17SP4	16EP4A	(2) 19	17AP4	(2) 22	19DP4A	(2) 24
16GP4       (2)19       17BP4B       (2)22       19GP4       (2)24         16HP4       (2)19       17BP4C       (2)22       19JP4       (2)24         16HP4A       (2)19       17CP4A       (2)22       20CP4       (2)24         16JP4       (2)19, 20       17FP4       (2)23       20CP4C       (2)24, 25         16KP4       (2)20       17FP4A       (2)23       20DP4       (2)25         16KP4A       (2)20       17HP4A       (2)23       20FP4       (2)25         16LP4       (2)20       17HP4A       (2)23       20FP4       (2)25         16MP4A       (2)20       17KP4       (2)23       20FP4       (2)25         16MP4A       (2)20       17KP4       (2)23       20HP4       (2)25         16MP4A       (2)20       17LP4       (2)23       20HP4       (2)25         16MP4A       (2)20       17LP4       (2)23       21EP4       (2)25         16MP4       (2)20       17LP4       (2)23       21EP4       (2)25         16RP4       (2)20       17QP4       (2)23       21EP4       (2)25         16SP4       (2)21       17QP4       (2)23       21EP4       (2)2	16EP4B	(2)19	17BP4	(2) 22	19EP4	(2) 24
16HP4       (2) 19       17BP4C       (2) 22       19JP4       (2) 24         16HP4A       (2) 19       17CP4       (2) 22       20CP4       (2) 24         16JP4       (2) 19, 20       17CP4A       (2) 22       20CP4C       (2) 24, 25         16KP4       (2) 19, 20       17FP4A       (2) 23       20DP4       (2) 25         16KP4       (2) 20       17HP4A       (2) 23       20DP4A       (2) 25         16KP4A       (2) 20       17HP4A       (2) 23       20FP4       (2) 25         16LP4A       (2) 20       17HP4A       (2) 23       20GP4       (2) 25         16MP4A       (2) 20       17KP4       (2) 23       20HP4       (2) 25         16MP4A       (2) 20       17LP4       (2) 23       20HP4       (2) 25         16MP4A       (2) 20       17LP4       (2) 23       20HP4B       (2) 25         16MP4       (2) 20       17LP4       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4       (2) 25         16SP4       (2) 21       17QP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 21       17QP4 <td< th=""><th>16FP4</th><th>(2)19</th><th>17BP4A</th><th>(2) 22</th><th>19FP4</th><th>(2) 24</th></td<>	16FP4	(2)19	17BP4A	(2) 22	19FP4	(2) 24
16HP4A       (2) 19       17CP4       (2) 22       20CP4       (2) 24         16JP4       (2) 19, 20       17CP4A       (2) 22       20CP4C       (2) 24         16JP4A       (2) 19, 20       17FP4       (2) 23       20CP4C       (2) 24, 25         16KP4       (2) 20       17FP4A       (2) 23       20DP4       (2) 25         16KP4A       (2) 20       17HP4A       (2) 23       20FP4       (2) 25         16LP4A       (2) 20       17JP4       (2) 23       20FP4       (2) 25         16MP4       (2) 20       17KP4       (2) 23       20HP4       (2) 25         16MP4A       (2) 20       17LP4       (2) 23       20HP4       (2) 25         16MP4A       (2) 20       17LP4       (2) 23       20HP4B       (2) 25         16QP4       (2) 20       17LP4A       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 21       17RP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 21       17SP4       (2) 23       21FP4A       (2) 25         16TP4       (2) 21       17VP4 <td< th=""><th>16GP4</th><th>(2)19</th><th>17BP4B</th><th>(2) 22</th><th>19GP4</th><th>(2) 24</th></td<>	16GP4	(2)19	17BP4B	(2) 22	19GP4	(2) 24
16JP4       (2) 19, 20       17CP4A       (2) 22       20CP4A       (2) 24         16JP4A       (2) 19, 20       17FP4       (2) 23       20CP4C       (2) 24, 25         16KP4       (2) 20       17FP4A       (2) 23       20DP4       (2) 25         16KP4A       (2) 20       17HP4A       (2) 23       20FP4       (2) 25         16LP4A       (2) 20       17JP4       (2) 23       20FP4       (2) 25         16MP4       (2) 20       17KP4       (2) 23       20HP4       (2) 25         16MP4A       (2) 20       17LP4       (2) 23       20HP4B       (2) 25         16RP4       (2) 20       17LP4A       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4       (2) 25         16RP4       (2) 21       17RP4       (2) 23       21EP4B       (2) 25         16SP4       (2) 21       17VP4       (2) 23       21FP4       (2) 26         16VP4       (2) 21       19AP4       (2)	16HP4	(2) 19	17BP4C	(2) 22	19JP4	(2) 24
16JP4A       (2) 19, 20       17FP4       (2) 23       20CP4C       (2) 24, 25         16KP4       (2) 20       17FP4A       (2) 23       20DP4       (2) 25         16KP4A       (2) 20       17HP4       (2) 23       20FP4       (2) 25         16LP4A       (2) 20       17JF4       (2) 23       20GP4       (2) 25         16MP4       (2) 20       17KP4       (2) 23       20HP4       (2) 25         16MP4A       (2) 20       17LP4       (2) 23       20HP4       (2) 25         16QP4       (2) 20       17LP4A       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4       (2) 25         16SP4       (2) 20       17QP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 21       17RP4       (2) 23       21EP4B       (2) 25         16SP4       (2) 21       17SP4       (2) 23       21FP4       (2) 25         16TP4       (2) 21       17UP4       (2) 23       21FP4       (2) 26         16UP4       (2) 21       17VP4       (2) 23       21FP4       (2) 26         16WP4       (2) 21       19AP4       (2) 24 <th>16HP4A</th> <th>(2)19</th> <th>17CP4</th> <th>(2) 22</th> <th>20CP4</th> <th>(2) 24</th>	16HP4A	(2)19	17CP4	(2) 22	20CP4	(2) 24
16KP4       (2) 20       17FP4A       (2) 23       20DP4       (2) 25         16KP4A       (2) 20       17HP4       (2) 23       20DP4A       (2) 25         16LP4       (2) 20       17HP4A       (2) 23       20FP4       (2) 25         16LP4A       (2) 20       17JP4       (2) 23       20HP4       (2) 25         16MP4A       (2) 20       17LP4       (2) 23       20HP4B       (2) 25         16MP4A       (2) 20       17LP4A       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4A       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 21       17RP4       (2) 23       21EP4B       (2) 25         16SP4       (2) 21       17SP4       (2) 23       21FP4       (2) 25         16TP4       (2) 21       17UP4       (2) 23       21FP4       (2) 25         16UP4       (2) 21       17VP4       (2) 23       21KP4       (2) 26         16WP4       (2) 21       19AP4A       (2) 24       21KP4       (2) 26         16WP4       (2) 21       19AP4B       (2) 24	16JP4	(2) 19, 20	17CP4A	(2) 22	20CP4A	(2) 24
16KP4A       (2) 20       17HP4       (2) 23       20DP4A       (2) 25         16LP4       (2) 20       17HP4A       (2) 23       20FP4       (2) 25         16LP4A       (2) 20       17JP4       (2) 23       20HP4       (2) 25         16MP4       (2) 20       17LP4       (2) 23       20HP4B       (2) 25         16MP4A       (2) 20       17LP4A       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 20       17QP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 21       17RP4       (2) 23       21EP4B       (2) 25         16SP4       (2) 21       17SP4       (2) 23       21FP4       (2) 25         16TP4       (2) 21       17UP4       (2) 23       21FP4A       (2) 26         16UP4       (2) 21       17VP4       (2) 23       21KP4       (2) 26         16WP4       (2) 21       19AP4A       (2) 24       21KP4A       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16XP4       (2) 22       19AP4C       (2) 24	16JP4A	(2) 19, 20	17FP4	(2) 23	20CP4C	(2) 24, 25
16LP4       (2) 20       17HP4A       (2) 23       20FP4       (2) 25         16LP4A       (2) 20       17JP4       (2) 23       20GP4       (2) 25         16MP4       (2) 20       17KP4       (2) 23       20HP4B       (2) 25         16MP4A       (2) 20       17LP4A       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 21       17RP4       (2) 23       21EP4B       (2) 25         16SP4A       (2) 21       17SP4       (2) 23       21FP4       (2) 25         16TP4       (2) 21       17UP4       (2) 23       21FP4A       (2) 26         16UP4       (2) 21       17VP4       (2) 23       21KP4       (2) 26         16WP4       (2) 21       19AP4       (2) 24       21KP4A       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16WP4A       (2) 22       19AP4C       (2) 24       21ZP4A       (2) 26	16KP4	(2) 20	17FP4A	(2) 23	20DP4	(2) 25
16LP4A       (2) 20       17JP4       (2) 23       20GP4       (2) 25         16MP4       (2) 20       17KP4       (2) 23       20HP4       (2) 25         16MP4A       (2) 20       17LP4       (2) 23       20HP4B       (2) 25         16QP4       (2) 20       17QP4       (2) 23       21EP4       (2) 25         16SP4       (2) 21       17RP4       (2) 23       21EP4B       (2) 25         16SP4A       (2) 21       17SP4       (2) 23       21FP4       (2) 25         16TP4       (2) 21       17UP4       (2) 23       21FP4       (2) 25         16UP4       (2) 21       17VP4       (2) 23       21FP4A       (2) 26         16WP4       (2) 21       19AP4       (2) 24       21KP4       (2) 26         16WP4A       (2) 21       19AP4A       (2) 24       21WP4       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16WP4A       (2) 22       19AP4C       (2) 24       21ZP4A       (2) 26	16KP4A	(2) 20	17HP4	(2) 23	20DP4A	(2) 25
16MP4       (2) 20       17KP4       (2) 23       20HP4       (2) 25         16MP4A       (2) 20       17LP4       (2) 23       20HP4B       (2) 25         16QP4       (2) 20       17LP4A       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 21       17RP4       (2) 23       21EP4B       (2) 25         16SP4A       (2) 21       17SP4       (2) 23       21FP4       (2) 25         16TP4       (2) 21       17UP4       (2) 23       21FP4A       (2) 26         16UP4       (2) 21       17VP4       (2) 23       21KP4       (2) 26         16WP4       (2) 21       19AP4       (2) 24       21KP4A       (2) 26         16WP4       (2) 21       19AP4A       (2) 24       21WP4       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16WP4       (2) 22       19AP4C       (2) 24       21ZP4A       (2) 26	16LP4	(2) 20	17HP4A	(2) 23	20FP4	(2) 25
16MP4A       (2) 20       17LP4       (2) 23       20HP4B       (2) 25         16QP4       (2) 20       17LP4A       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 21       17RP4       (2) 23       21EP4B       (2) 25         16SP4A       (2) 21       17SP4       (2) 23       21FP4       (2) 25         16TP4       (2) 21       17UP4       (2) 23       21FP4A       (2) 26         16UP4       (2) 21       17VP4       (2) 23       21KP4       (2) 26         16VP4       (2) 21       19AP4       (2) 24       21KP4A       (2) 26         16WP4       (2) 21       19AP4A       (2) 24       21WP4       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16XP4       (2) 22       19AP4C       (2) 24       21ZP4A       (2) 26	16LP4A	(2) 20	17JP4	(2) 23	20GP4	(2) 25
16QP4       (2) 20       17LP4A       (2) 23       21EP4       (2) 25         16RP4       (2) 20       17QP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 21       17RP4       (2) 23       21EP4B       (2) 25         16SP4A       (2) 21       17SP4       (2) 23       21FP4       (2) 25         16TP4       (2) 21       17UP4       (2) 23       21FP4A       (2) 26         16UP4       (2) 21       17VP4       (2) 23       21KP4       (2) 26         16VP4       (2) 21       19AP4       (2) 24       21KP4A       (2) 26         16WP4       (2) 21       19AP4A       (2) 24       21WP4       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16XP4       (2) 22       19AP4C       (2) 24       21ZP4A       (2) 26	16MP4	(2) 20	17KP4	(2) 23	20HP4	(2) 25
16RP4       (2) 20       17QP4       (2) 23       21EP4A       (2) 25         16SP4       (2) 21       17RP4       (2) 23       21EP4B       (2) 25         16SP4A       (2) 21       17SP4       (2) 23       21FP4       (2) 25         16TP4       (2) 21       17UP4       (2) 23       21FP4A       (2) 26         16UP4       (2) 21       17VP4       (2) 23       21KP4       (2) 26         16VP4       (2) 21       19AP4       (2) 24       21KP4A       (2) 26         16WP4       (2) 21       19AP4A       (2) 24       21WP4       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16XP4       (2) 22       19AP4C       (2) 24       21ZP4A       (2) 26	16MP4A	(2) 20	17LP4	(2) 23	20HP4B	(2) 25
16SP4       (2) 21       17RP4       (2) 23       21EP4B       (2) 25         16SP4A       (2) 21       17SP4       (2) 23       21FP4       (2) 25         16TP4       (2) 21       17UP4       (2) 23       21FP4A       (2) 26         16UP4       (2) 21       17VP4       (2) 23       21KP4       (2) 26         16VP4       (2) 21       19AP4       (2) 24       21KP4A       (2) 26         16WP4       (2) 21       19AP4A       (2) 24       21WP4       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16XP4       (2) 22       19AP4C       (2) 24       21ZP4A       (2) 26	16QP4	(2) 20	17LP4A	(2) 23	21EP4	(2) 25
16SP4A       (2) 21       17SP4       (2) 23       21FP4       (2) 25         16TP4       (2) 21       17UP4       (2) 23       21FP4A       (2) 26         16UP4       (2) 21       17VP4       (2) 23       21KP4       (2) 26         16VP4       (2) 21       19AP4       (2) 24       21KP4A       (2) 26         16WP4       (2) 21       19AP4A       (2) 24       21WP4       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16XP4       (2) 22       19AP4C       (2) 24       21ZP4A       (2) 26	16RP4	(2) 20	17QP4	(2) 23	21EP4A	(2) 25
16TP4       (2) 21       17UP4       (2) 23       21FP4A       (2) 26         16UP4       (2) 21       17VP4       (2) 23       21KP4       (2) 26         16VP4       (2) 21       19AP4       (2) 24       21KP4A       (2) 26         16WP4       (2) 21       19AP4A       (2) 24       21WP4       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16XP4       (2) 22       19AP4C       (2) 24       21ZP4A       (2) 26	16SP4	(2)21	17RP4	(2) 23	21EP4B	(2) 25
16UP4       (2) 21       17VP4       (2) 23       21KP4       (2) 26         16VP4       (2) 21       19AP4       (2) 24       21KP4A       (2) 26         16WP4       (2) 21       19AP4A       (2) 24       21WP4       (2) 26         16WP4A       (2) 21       19AP4B       (2) 24       21ZP4       (2) 26         16XP4       (2) 22       19AP4C       (2) 24       21ZP4A       (2) 26	16SP4A	(2) 21	17SP4	(2) 23	21FP4	(2) 25
16VP4       (2)21       19AP4       (2)24       21KP4A       (2)26         16WP4       (2)21       19AP4A       (2)24       21WP4       (2)26         16WP4A       (2)21       19AP4B       (2)24       21ZP4       (2)26         16XP4       (2)22       19AP4C       (2)24       21ZP4A       (2)26	16TP4	(2) 21	17UP4	(2) 23	21FP4A	(2) 26
16WP4       (2)21       19AP4A       (2)24       21WP4       (2)26         16WP4A       (2)21       19AP4B       (2)24       21ZP4       (2)26         16XP4       (2)22       19AP4C       (2)24       21ZP4A       (2)26	16UP4	(2) 21	17VP4	(2) 23	21KP4	(2) 26
16WP4A (2) 21 19AP4B (2) 24 21ZP4 (2) 26 16XP4 (2) 22 19AP4C (2) 24 21ZP4A (2) 26	16VP4	(2) 21	19AP4	(2)24	21KP4A	(2) 26
16XP4 (2)22 19AP4C (2)24 21ZP4A (2)26	16WP4	(2) 21	19AP4A	(2)24	21WP4	(2) 26
	16WP4A	(2) 21	19AP4B	(2) 24	21ZP4	(2) 26
16YP4 (2) 22 19AP4D (2) 24 22AP4 (2) 26	16XP4	(2) 22	19AP4C	(2)24	21ZP4A	(2) 26
	16YP4	(2) 22	19AP4D	(2) 24	22AP4	(2)26
16ZP4 (2) 22 19DP4 (2) 24 22AP4A (2) 26	16ZP4	(2) 22	19DP4	(2) 24	22AP4A	(2) 26

	TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
	24AP4	(2) 26	27EP4	(2) 26	27NP4	(2) 26
	24AP4B	(2) 26	27GP4	(2) 26	27RP4	(2) 26
						•
ŀ						
		7				
L		i	1			