

Replacement Radio Battery Cross Reference Chart

	Olin	Bright Star	Burgess	Eveready	General	Philco	RCA	Ray-O-Vac	USA Lite	Willard
"A" Batteries										
1 1/2	1311-101	11M	1	935	C	C	VS033	1LP		C
1 1/2		60A					VS070			
1 1/2	1511-102	10A	2	950	D--35	D	VS036	2R	75	D
		2516					VS001			
1 1/2	4816	462	4F	742	4F1--3	P94	VS004	P94A	634	4F1
1 1/2	4814	660	6F	743	6F1--5		VS007	P94A	637	6F1
1 1/2	4819	860	8F	741	8F1--6	P8F1		P98A	635	8F1
1 1/2		465	4FL		3L1--13		VS005	P94L	642	WA-1-7
1 1/2					4L1--954	P4L1				4L1
1 1/2		26-60	20F	740	12L1L--15		VS024	P9203		
1 1/2			19G		12L1S--16					12L-1S
1 1/2	4813	865		745			VS008	P94L	645	
3		40-60	20F2	X125	P24L2	P8024	VS025	P9403		P24L2
4 1/2	4918	361	G3	746	3H3--8	P100	VS002	P93A	683	WA3-1
4 1/2	3816	360	F3	736	3F3--38		VS067	P93A		
6	4919			724						
6	4914	646	F4P1	744	4F4--4	P4F4R	VS009	P694A	639	WA4-2
6	4817	866	2F4	718	8F4--7		VS010	P694A	638	WA4-1
6	4815	868	2F4L	747			VS011	P694L	646	
7 1/2		561	G5	687	5H5		VS003	P85A	687	WA5-1
7 1/2	5316		C5	717	31		VS065	P751		
"B" Batteries										
45	6211		XX30	455	W30A--105		VS055			
45	6518	30-95	2308	487**	V30D--115	P30D	VS026	P2303		V30D1
45		30-60	10308	386	V30F--119	P30F	VS027	P5933		V30F
45			21308		V30FL--121	P30FL		P9303		V30FL
45		30-03	B-30	762*	V30B--111	P305	VS012	P5303	624	V30B
45		30-55	A-30		V30A--110	P210	VS014	P430	621	V30A
45					F30A--107	P200				WB6
45	6210	30-33	M-30	482	W30B--109	P45	VS013	P7830	640	WBM-1
45		30-59	Z-30	738	V30AA--104		VS015	P7R30	620	V30AA
45										
67 1/2	1710	45M	XX-45	467	W45A--108	P67	VS016	4367	767	WBM-2
67 1/2	1712			457						
90	1713	60N	N60	490	W60A--132		VS090	4390		WBM-3
"C" Batteries										
4 1/2	3217		5360	781	H3BS--201		VS028	531R		H-3-B
4 1/2	3516	71-17	2370	771	H3D--215	P3D	VS030	P231W		H-3-D
7 1/2	5218	51-03	5540	773	V5B--208	P5B	VS029	551		V5B
22 1/2			4156	763	H15A--003		VS102	4151		
22 1/2	5216	15-03	5156	768	H15B5--212	P15B5	VS031	P5151		H15B
22 1/2	5216-8		5156	778	H15B--210		VS131	5151		
Battery Packs										
1 1/2	60				254	P89				WP-4
1 1/2	61 1/2		4GA42		258	P41A4FL	VS053	AB419	AB669	WP-1
7 1/2	63		G5A42		259	P87	VS038	AB794	AB676	
6	75		G4B50		Z50B4H4		VS046		AB670	
1 1/2	90	0513	4SD60	758	60B6L--299	P60B6L	VS021	AB85		WZ-2
1 1/2	90	0518	17GD60	759	328	P60D11L	VS022	AB82	AB666	60B6L
1 1/2	90		5DA60		60A2L--278		VS043	AB24		60D11L
1 1/2	90		GFA60		60A4L--279	P60A4L	VS037	AB84	AB667	WP-2
9	90	0512	3G6D60		320			AB982		WP-3
9	90	0616	G6B60	752	343	P60B6F6	VS047	AB995	AB677	
7 1/2, 9	90	0619		756	362	P363	VS057	AB601		WZ-3
7 1/2, 9	90	0614	F6A60	753	60A6F6/5--271	P841A	VS019	AB994		AB-15
7 1/2, 9	90				60B6F6-5					60A6F6/5
7 1/2, 9	90	0615	G6M60	754	291		VS018	AB994		60B-6F6/5
9	135		F90D6		90FL6D	P9068				AB14
7 1/2	67 1/2		F5M45				VS020	AB767		96H
1 1/2	67 1/2	7 1/2					VS041			
6	90		F4B60		270		VS048			
6	90		2FA60				VS044			
7 1/2	75	0618	T5Z50	755		41A4G	VS050	AB775		
1 1/2	61		4GA41				VS052			
1 1/2	90		6TA60				VS054			
9	90		F6A60P				VS058	AB909		
1 1/2	90	0511	18GD60		318		VS045			
6	75		3G4D50				VS049			

NOTES:
 # Numbers separated by -- indicates that first number shown is new number, second is old.
 * Eveready 762 discontinued; use Ev. 482.
 ** All Eveready farm radio 45 volt "B" may be replaced with Ev. 487.
 Radio storage batteries: Willard No's. Radio 25-2, ER342, ER242 or Radio 20-2 are 2 volts. Radio 190-6 is 6 volt battery.

Most Popular Types

Type	Olin	Bright Star	Burgess	Eveready	General	Philco	RCA	Ray-O-Vac	USA Lite	Willard
A	4816	462	4F	742	4F1-3	P94	VS004	P94A	634	4F1
A	1511-102	10A	2R	950	35	D	VS036	2R	75	D
A	4918	361	G3	746	3H3-8	P100	VS002	P93A	683	WA3-1
A	3816	360	F3	736	38		VS067	P93A		
A	5316		C5	717	31		VS065	P751		
B	1710	45M	XX45	467	W45A-108	P67	VS016	4367	767	WBM-2
B	1713	60N	N60	490	W60A-132		VS090	4390		WBM-3
B	6210	30-33	M30	482	W30B-109	P45	VS013	P7830	640	WBM-1
AB	0614	66-50	F6A60	753	60A6F65-271	P841A	VS019	AB994		60A6F65
AB	0618		T5Z50	755			VS050	AB775		
AB	0619			756	362	P363	VS057	AB601		AB15