Follow these easy steps

A weak, shorted, or dead receiving tube will cause different effects on the picture, or will affect the sound or possibly both picture and sound. If you know which tubes to test, many color and black and white TV troubles can be corrected by testing only a few tubes.


If your TV set uses receiving tubes the following tips will help you in

A VISUAL INSPECTION can save you some time. Look through the perforated back cover of the set for tubes that are not lit, flash internally or that glow a deep purple. You will want to test these tubes first.

determining which tubes you should test and how to go about it.

- B. COMPARE THE SYMPTOMS YOUR SET HAS WITH THOSE PICTURED at the right. The numbers beneath each picture identifies the tubes by function which are most likely to be causing the trouble and should be tested. When repairing a color set, the first step is to correct any black and white picture problems. You can't get a good color picture if you can't get a good black and white picture. Most of the tubes in a color set have the same function that they do in a black and white set.
- tube location chart. It is usually glued to the inside or back of the cabinet. This chart, gives the *tunctions*, type numbers and positions on the chassis of all the tubes. If a layout chart isn't available, make a sketch of the chassis carefully noting the position of each tube so that they can be returned to their original sockets.
- D. TO GET AT THE TUBES YOU MUST REMOVE THE BACK OF THE SET. First, disconnect the power by unplugging the set at the well outlet. Then, remove the screws that secure the back cover, CAUTION: HIGH VOLTAGES MAY BE PRESENT AT CERTAIN POINTS IN THE SET LONG AFTER THE POWER HAS BEEN TURNED OFF—DO NOT TOUCH THE PICTURE TUBE, PICTURE TUBE HIGH VOLTAGE LEAD WIRE OR ANY METAL WITHIN THE HIGH VOLTAGE CAGE.
- ing away from the socket. Some tubes may be covered with metal covers called shields. Some can be removed by simply lifting it off the tube, others you simply press down and twist slightly and lift up. Most tuner tubes use a telescopic type shield whereby you press down on the upper portion of the shield and then remove the tube.
- that come with this brochure as you remove each tube. This will avoid a mix up when you put the tubes back. A lot of tubes look allke but have entirely different electrical connections and properties. Putting them in the wrong sockets can damage the tubes and other set components.
- EASY. Simply follow the instructions on the tester panel. Testers do vary somewhat in operation and design. On most you look up the tube type number in a chart, set a few controls, insert the tube in the specified socket. press the test switch and read the condition of the tube on a meter and/or indicator lamps. You will find a complete stock of nationally advertised replacement tubes at all tester locations.
- any new ones you need, install them in the set. Make certain to put them in the right sockets. Remove the identification labels you have placed on the tubes and sockets one at a time. Be sure to replace all tube shields and the high voltage cage panel if it has been removed to gain access to the tubes.

Replace the back cover. Make sure that the interlock connection to the power cord is properly seated and making contact and that the antenna is connected. Plug the set in, turn it on, and enjoy your favorite program.



FREE GUIDE

SELF-SERVICE

The string in your doubtful tubes and test them here SAVE TIME and

IT'S SIMPLE AS 1-2-3!

and the tubes that usually cure them COLOR and BLACK & WHITE TV TROUBLES



WEAK SNOWY PICTURE OR NO PICTURE. WEAK OR NO SOUND SEE STEP. . . 1



SCREEN LIGHTED NORMAL OR NO SOUND SEE STEPS 1. 2. 8 3



WEAK, OR DISTORTED SOUND SEE STEPS 1, 2, 3, 4, & 5



PICTURE BENDS SOUND OK 'S ... 2. 3, 6, 7, & 11 SEE STEPS



SEE STEPS 7. & 6







COLOR BARS THROUGH PICTURE SOUND OK SEE STEP ... 16




BAND THROUGH PICTURE SOMETIMES HUM IN SOUND SEE STEP 17

for the following tube types: 2BN4, 2CW4, 3HM5, 3HQ5, 4HQ5, 6CW4, 6DS4, RF AMPLIFIER TUBE. Located on tuner. 6HA5, 6HQ5, 6FH5, 6FQ5. 3HA5. 6GK5. 2CY5

OSCILLATOR MIXER TUBE. Located on Look for tube types such as 5CG8, 5CL8, ', 5GX7, 5KE8, 5EA8, 6AT8, 6BE8, 6BR8, 6CG8, 6CL8, 6EA8, 6FG7, 6HB7, 6KE8, 6KZ8, 6LJ8, 5U8, 7HG8, 9KZ8. , 5GS7 EST. 5GJ7, tuner.

three, or four miniature tubes in a line. Look for tube lypes such as: 3BZ6, 3CB6, 4BZ6, 4CB6, 4EH7, 4FJ7, 4HM6, 4HT6, 4JC6, 4JD6, 5AN8, 6AR11, 6BZ6, 6CB6, 6EJ7, 6EW6, 6GM6, 6HM6, 6HT6, 6JC6, 6JN8, TEST VIDEO (PICTURE) IF TUBES. Usually two 8BM11, 11BQ11 TEST VIDEO AMPLIFIER OR VIDEO OUTPUT 6AW8, 6CX8, 6GN8, 6HF8, 6JA8, 6LQ8, 8AW8, 8JV8, 0LZ8, 11KV8, 11LQ8, 12BY7, 14BL11, 14BR11, TUBE. Typical type numbers are: 6AF11, 6AU8, 10HF8, 10JY8, 10GN8, OCW5, 10EB8, 5BD11, 16GK6. TEST SOUND IF, DETECTOR, AND AMPLIFIER TUBES. Look for types such as: 3CB6, 4AU6, 4CS6, 6FV8, 6GH8, 6HF8, 6HZ6, 6LN8, 6LX8, 6T10, 8JV8, 9A8, 10GN8, 10HG8, 10JY8, 12AE10, 12BA6, 13V10, 6DT6 4DT6, 6AF11, 6AU6, 6BN6, 6BN8, 6GL8, 13Z10, 14BL11, 14BR11, 15BD11, 17BF11.

6GH5, 6T10, 10JY8, 11BM8, 12AE10, 12FX5, 13V10, TEST SOUND (AUDIO) OUTPUT TUBE. Look for tube types such as: 5AQ5, 6AQ5, 6BK5, 6CU5, 6EH5 13Z10, 16GK6, 17BF11, 17C5, 17CU5, 50C5.



9, 10, 11, 12, & 13


SEE STEPS ...

DIAGONAL LINES SOUND OK STEPS . . . 7. 9. & 11

LACKS WIDTH



NO COLOR—B/W PICTURE OK SOUND OK SEE STEP . . . 14



TEST AGC TUBES. Look for tube types such as: 4AU6, 4HS8, 6CL8, 6FV8, 6GH8, 6GY6, 6JN8, 6LQ8, 6LX8, 8B10, 8BA11, 8JV8, 8KA8, 9A8, 10GN8, 0JY8, 11BM8, 11KV8, 11LQ8, 14BL11, 14BR11, 5BD11.

one part of a dual-function tube. Typical type TEST SYNC (SYNCHRONIZING) TUBES. Often numbers. 4HS8, 6AF11, 6AV6, 6FQ7, 6GH8, 6GN8, 6JA8, 6JE8, 6KA8, 6HS8, 6LN8, 6LX8, 8B10, 8BA11, 8KA8, 9A8, 10EB8, 10GN8, 10JY8, 10KR8, 8JV8,

OUTPUT TUBES. They may be two tubes or one dual-function tube. Look for tube types such as: 6CG7, 6DE7, 6DR7, 6EA7, 6EM5, 6EM7, 6FQ7, 6FY7, 6JZ8, 6KY8, 8AW8, 8BA11, 8CG7, 8FQ7, 9A8, TEST VERTICAL OSCILLATOR AND VERTICAL 0CW5, 10DE7, 10GK6, 10GV8, 13FM7, 13GF7, 15KY8, 16GK6, 17JZ8, 21LR8, 23Z9.

lype numbers: 6DQ6, 6GE5, 6GW6, 6GY5, 6JB6, Usually 6JE6, 6JF6, 12DQ6, 12GE5, 12JN6, 17JB6, 17JN6, 8GB5, 21GY5, 21JZ6, 21KA6, 21KQ6, 22JF6, 22JU6, 33GY7, 33GT7, 38HE7, 38HK7, 33JV6. located near high-voltage compartment. TEST HORIZONTAL OUTPUT TUBE.

TEST DAMPER TUBE. Look for tube type such as: 6AD4, 6AU4, 6AX4, 6AY3, 6BE3, 6CK3, 6CQ4, 11R3, 12BR3, 12RK19, 16AQ3, 17AY3, 17BS3, 17BZ3, 20AQ3, 22BW3, 33GY7, 38HE7, 38HK7. 2AF3, 17BR3,

TEST HORIZONTAL OSCILLATOR TUBE. Typical type numbers: 5KD8, 6B10, 6CG7, 6EA8, 6FQ7, 6GH8, 6LN8, 6LT8, 6LX8, 8B10, 8CG7, 8FQ7, 8LT8, 9A8, 12BH7. NOTE: If this type is replaced, you may

have to readjust the horizontal frequency or drive

WHEN REPLACING THIS TUBE. The base of this tube connects to the picture tube, which stores a very high voltage, even after set is turned off. To be TEST HIGH VOLTAGE RECTIFIER TUBE. Located nside the metal high-voltage compartment. Typical iype numbers: 1AD2, 1BC2, 1BK2, 1BL2, 1G3, 1K3, 1X2, 2AS2, 3A3, 3AT2. CAUTION: BE CAREFUL safe, do not touch any metal in the high voltage compartment. If top cap of tube is metal, use an insulated ool to remove the cap.

TEST LOW VOLTAGE RECTIFIER TUBE. Look for tubes such as: 3DG4, 5BC3, 5DJ4, 5U4. Most modern sets use semiconductor diodes which must be replaced by a service technician.

CHROMA PHASE DETECTOR TUBES. Typical tube CHROMA OSCILLATOR, BURST AMPLIFIER AND 6JC6, 6JU8, 6KT8, 6LN8, 6M11, 8BN11, 8BU11, TEST COLOR KILLER, CHROMA AMPLIFIER, lypes are: 6AF9, 6BL8, 6BN8, 6BW11, 6EW6, 6GH8, 9MN8 and 10JT8.

DIFFERENCE AMPLIFIER TUBES. Typical tube TEST ALL COLOR DEMODULATOR TUBES AND lypes are: 6AC10, 6BL8, 6BU11, 6DB6, 6GH8, 6GU7, 6GY6, 6HZ6, 6JU8, 6LE8, 6MD8, 6ME8, 6ML8, 8FQ7 12AZ7, 12BV11 and 12MN8.

PHASE DETECTOR TUBE. Typical tube types are TEST BURST AMPLIFIER TUBE AND CHROMA 6BN8 and 6JU8. TEST ALL TUBES. Just about any tube in the set can cause this problem. Be on the lookout for one